

AIRWORTHINESS DIRECTIVE SUMMARY SUBJECT INDEX

SMALL AIRCRAFT

APRIL 2001

Q-Z

(Also see applicable rotorcraft, engine, propeller and appliance notes)

* * * * *

The indexes, which are published twice a year, are intended to be used as a guide only and should not be relied upon as conclusive evidence of AD applicability. Aircraft operators, inspectors, and persons performing maintenance are reminded of their responsibility under Sections 39.3, 43.11, and 43.13 of the Federal Aviation Regulations, respectively, to assure compliance with all applicable AD's.

* * * * *

SMALL AIRCRAFT MAKE & MODEL	TC NO.	AD NUMBER	* SUBJECT	BOOK NO.
RAVEN INDUSTRIES, INC.				
<i>(See AEROSTAR)</i>				
RAYTHEON AIRCRAFT CORPORATION				
<i>(Formerly BEECH AIRCRAFT)</i>				
<i>(For AD's in Book 1 and 2 See Beech)</i>				
Army AT-11, Navy SNB-1	A-2-582	47-06-08 47-06-09 47-30-06 47-30-07 47-33-03 47-33-05 48-14-03 48-34-01 48-51-01 49-15-03 65-03-01 75-27-09	R2 Starter solenoid and buss lead wires Landing gear retracting mechanism Generator relay control switch Tripfree circuit breaker Tail cone drain holes Horizontal stabilizer spar Wing center section spar Stabilizer attachment fittings Control wheel shaft inspection Fuel tank vent system Gap seal strips Wing structure	Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1
D17S	A-649	48-51-01	Control wheel shaft inspection	Bk 1
C18S	A-757	47-06-08 47-06-09 47-33-03 47-33-04 47-33-05 48-14-03 48-34-01 48-51-01 49-15-03 65-03-01 75-27-09 77-19-07	R2 Starter solenoid and buss lead wire Landing gear retracting mechanism Tail cone drain holes Fuel tank gaskets Horizontal stabilizer spar Wing center section spar Stabilizer attachment fittings Control wheel shaft inspection Fuel tank vent system Gap seal strips Wing structure Control column assembly	Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1
D18C	A-765	47-33-06 47-33-07 47-34-01 47-34-02 47-34-03 48-13-01	Stabilizer spar replacement Alternate static source Expansion type filler cap Tail cone drain holes Fuel cell seal Generator control box insulation	Bk 1 Bk 1 Bk 1 Bk 1 Bk 1 Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		48-34-01	Stabilizer attachment fittings	Bk 1
		49-29-02	Rudder spring bushings	Bk 1
		66-30-01	Static pressure line	Bk 1
		68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
D18S	A-765	47-33-05	Horizontal stabilizer spar	Bk 1
		47-33-06	Stabilizer spar replacement	Bk 1
		47-33-07	Alternate static source	Bk 1
		47-34-01	Expansion type filler cap	Bk 1
		47-34-02	Tail cone drain holes	Bk 1
		47-34-03	Fuel cell seal	Bk 1
		48-13-01	Generator control box insulation	Bk 1
		48-34-01	Stabilizer attachment fittings	Bk 1
		49-29-02	Rudder spring bushings	Bk 1
		59-18-02	Fuel line modification	Bk 1
		65-03-01	Gap seal strips	Bk 1
		66-30-01	Static pressure line	Bk 1
		68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
E18S	A-765	56-20-01	Tail wheel axle	Bk 1
		65-03-01	Gap seal strips	Bk 1
		66-30-01	Static pressure line	Bk 1
		68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
E18S-9700	A-765	66-30-01	Static pressure line	Bk 1
		68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
G18S	A-765	68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
H18	A-765	68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT					BOOK
MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	NO.
		77-19-07		Control column assembly	Bk 1
		78-10-01		Lower rudder torque tube	Bk 1
		81-18-07		Volpar tri-gear	Bk 2
18A, S18A	TC 630	75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
18D, S18D, A18A, SA18A, A18D, SA18D	A-684	75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
18S (C-45C) B18S (F-2)	TC 710	75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
C-45 Series	A-757 & A-765	65-03-01		Gap seal strips	Bk 1
		75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
C-45G	A-765	59-18-02		Fuel line modification	Bk 1
		60-16-01		Emergency elec. switch/seats	Bk 1
		66-30-01		Static pressure line	Bk 1
		68-23-06		Volpar tri-gear	Bk 1
		72-16-02	R3	Volpar nose gear fork	Bk 1
		72-25-06		Nose gear extension	Bk 1
		75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
		78-10-01		Lower rudder torque tube	Bk 1
		81-18-07		Volpar tri-gear	Bk 2
TC-45G	A-765	59-18-02		Fuel line modification	Bk 1
		60-16-01		Emergency elec. switch/seats	Bk 1
		66-30-01		Static pressure line	Bk 1
		68-23-06		Volpar tri-gear	Bk 1
		72-16-02	R3	Volpar nose gear fork	Bk 1
		72-25-06		Nose gear extension	Bk 1
		75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
		78-10-01		Lower rudder torque tube	Bk 1
		81-18-07		Volpar tri-gear	Bk 2
C-45H	A-765	59-18-02		Fuel line modification	Bk 1
		60-16-01		Emergency elec. switch/seats	Bk 1
		66-30-01		Static pressure line	Bk 1
		68-23-06		Volpar tri-gear	Bk 1
		72-16-02	R3	Volpar nose gear fork	Bk 1
		72-25-06		Nose gear extension	Bk 1
		75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
		78-10-01		Lower rudder torque tube	Bk 1
		81-18-07		Volpar tri-gear	Bk 2
TC-45H	A-765	59-18-02		Fuel line modification	Bk 1
		60-16-01		Emergency elec. switch/seats	Bk 1
		68-23-06		Volpar tri-gear	Bk 1
		72-16-02	R3	Volpar nose gear fork	Bk 1
		72-25-06		Nose gear extension	Bk 1
		75-27-09	R2	Wing structure	Bk 1
		77-19-07		Control column assembly	Bk 1
		81-18-07		Volpar tri-gear	Bk 2
TC-45J (SNB-5)	A-765	66-30-01		Static pressure line	Bk 1
		68-23-06		Volpar tri-gear	Bk 1
		72-16-02	R3	Volpar nose gear fork	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
JRB-6	A-765	66-30-01	Static pressure line	Bk 1
		68-23-06	Volpar tri-gear	Bk 1
		72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
3N, 3NM, 3TM,	A-765	72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		78-10-01	Lower rudder torque tube	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
RC-45J (SNB-5P)	A-765	72-16-02	R3 Volpar nose gear fork	Bk 1
		72-25-06	Nose gear extension	Bk 1
		75-27-09	R2 Wing structure	Bk 1
		77-19-07	Control column assembly	Bk 1
		81-18-07	Volpar tri-gear	Bk 2
17 Series		99-05-13	Fuel tank selector.....	BW 00-14
18 Series		99-05-13	Fuel tank selector.....	BW 00-14
19 Series		99-05-13	Fuel tank selector.....	BW 00-14
23 All Models	A1CE	64-06-01	Cabin heater/muffler weld assy	Bk 1
		99-05-13	Fuel tank selector.....	BW 00-14
23	A1CE	63-06-01	Cabin door hinge	Bk 1
		65-11-01	Instrument static system	Bk 1
		65-19-02	Aileron control column links	Bk 1
		68-17-06	Parking brake	Bk 1
		70-15-03	Fuel selector valve	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		74-23-09	Inflight situations	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
A23	A1CE	65-19-02	Aileron control column links	Bk 1
		68-17-06	Parking brake	Bk 1
		70-15-03	Fuel selector valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		75-01-04	Fuel selector valve	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
A23A	A1CE	68-17-06	Parking brake	Bk 1
		70-15-03	Fuel selector valve	Bk 1
		71-25-03	Fuel and oil restrictor	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
A23-19	A1CE	68-17-06	Parking brake	Bk 1
		70-15-03	Fuel selector valve	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		74-23-09	Inflight situations	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
19A	A1CE	70-15-03	Fuel selector valve	Bk 1
		71-25-03	Fuel and oil restrictor	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		74-23-09	Inflight situations	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
B19	A1CE	71-25-03	Fuel and oil restrictor	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		73-25-04	Maximum design weight placard	Bk 1
		74-05-01	Restricted fuel vent tank lines	Bk 1
		74-14-02	Carburetor and air controls	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		74-14-05	Placard, spins	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-10-09	Wing flaps	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		78-16-06	Structural integrity of trim tab rod	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
M19A	A1CE	71-25-03	Fuel and oil restrictor	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		74-23-09	Inflight situations	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
A23-24	A1CE	68-17-06	Parking brake	Bk 1
		70-15-03	Fuel selector valve	Bk 1
		71-25-03	Fuel and oil restrictor	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		88-10-01	Fuel boost pump	Bk 2
		89-24-09	Aileron rod ends	Bk 2
B23	A1CE	70-15-03	Fuel selector valve	Bk 1
		71-25-03	Fuel and oil restrictor	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1
		74-23-09	Inflight situations	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
C23	A1CE	71-25-03	Fuel and oil restrictor	Bk 1
		73-12-11	Carburetor air box valve	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		73-23-06	Throttle control cable	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		74-05-01	Restricted fuel tank vent lines	Bk 1
		74-14-02	Carburetor and air controls	Bk 1
		74-14-05	Placard, spins	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-10-09	Wing flaps	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		78-16-06	Structural integrity of trim tab rod	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		89-24-09	Aileron rod ends	Bk 2
24 Series		99-05-13	Fuel tank selector	BW 00-14
A24	A1CE	71-25-03	Fuel and oil restrictor	Bk 1
		73-20-07	R2 Wing attach bolts/brackets	Bk 1
		73-23-03	Flexible induction air ducts	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		77-03-05	Main landing gear	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		88-10-01	Fuel boost pump	Bk 2
		89-24-09	Aileron rod ends	Bk 2
A24R	A1CE	71-25-03	R2 Fuel and oil restrictor	Bk 1
		73-20-07	Wing attach bolts/brackets	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		76-25-05	Aileron control	Bk 1
		78-04-01	Wing flap control	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		88-10-01	Fuel boost pump	Bk 2
		89-24-09	Aileron rod ends	Bk 2
B24R	A1CE	73-20-07	R2 Wing attach bolts/brackets	Bk 1
		74-05-01	Restricted fuel tank vent lines	Bk 1
		75-01-04	Fuel selector valve	Bk 1
		75-17-37	Carburetor mixture and/or heat control	Bk 1
		75-20-08	Propeller governor	Bk 1
		76-10-09	Wing flaps	Bk 1
		78-04-01	Wing flap control	Bk 1
		78-16-06	Structural integrity of trim tab rod	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		88-10-01	Fuel boost pump	Bk 2
		89-24-09	Aileron rod ends	Bk 2
C24R	A1CE	78-04-01	Wing flap control	Bk 1
		78-16-06	Structural integrity of trim tab rod	Bk 1
		85-05-02	Fuel selector guard mod.	Bk 2
		87-02-08	Stabilator hinge assemblies	Bk 2
		88-10-01	Fuel boost pump	Bk 2
T-34C (T-34C-1, 34C)	A26CE	80-07-05	Bolt and nut, wing section	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		92-15-01	Truss-to-firewall bolt	Bk 3
		94-04-18	Elevator arm assembly	Bk 3
		95-04-10	Wing attach bolts	Bk 3
35 All Models (Series)	A-777, 3A15	49-26-01	Trailing antenna rework	Bk 1
		49-48-01	Thompson fuel pump	Bk 1
		51-14-01	Fuel booster pump removal	Bk 1
		55-22-01	Oil outlet check valve	Bk 1
		62-08-03	Control wheels	Bk 1
		69-18-01	Fuel system modification	Bk 1
		84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
35	A-777	47-47-07	Engine identification plate	Bk 1
		47-47-08	Fuel line chafing	Bk 1
		48-08-01	Starter rework	Bk 1
		49-04-01	Aileron chain	Bk 1
		49-31-01	Emergency fuel pump "O" rings	Bk 1
		53-01-02	Fuel selector valve rework	Bk 1
		62-08-03	Control wheels	Bk 1
		63-25-01	Fuselage modification	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-18-01	Fuel selector valve warning light	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-05-04	Stabilizer attach fitting	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		98-13-02	Placard - Speed	Bk 3
A35	A-777	49-26-01	Trailing antenna rework	Bk 1
		49-31-01	Emergency fuel pump "O" rings	Bk 1
		49-48-01	Thompson fuel pump	Bk 1
		50-42-01	Elevator tab replacement	Bk 1
		51-14-01	Fuel booster pump removal	Bk 1
		53-01-02	Fuel selector valve rework	Bk 1
		59-08-01	Landing gear limit switches	Bk 1
		62-08-03	Control wheels	Bk 1
		63-25-01	Fuselage modification	Bk 1
		69-18-01	Fuel system modification	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-18-01	Fuel selector valve warning light	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-05-04	Stabilizer attach fitting	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		98-13-02	Placard - Speed	Bk 3
B35	A-777	53-01-02	Fuel selector valve rework	Bk 1
		59-08-01	Landing gear limit switches	Bk 1
		62-08-03	Control wheels	Bk 1
		63-25-01	Fuselage modification	Bk 1
		69-18-01	Fuel system modification	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-18-01	Fuel selector valve warning light	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		75-15-08	Engine lubrication	Bk 1
		76-05-04	Stabilizer attach fitting	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		98-13-02	Placard - Speed	Bk 3
C35	A-777	53-01-02	Fuel selector valve rework	Bk 1
		59-08-01	Landing gear limit switches	Bk 1
		62-08-03	Control wheels	Bk 1
		69-18-01	Fuel system modification	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-18-01	Fuel selector valve warning light	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
D35	A-777	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
E35	A-777	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
F35	A-777	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
G35	A-777	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
35R	A-777	63-25-01	Fuselage modification	Bk 1
		72-11-02	Engine fuel interruption	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-05-04	Stabilizer attach fitting	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		98-13-02	Placard - Speed	Bk 3
H35	3A15	62-08-03	Control wheels	Bk 1
		65-14-01	Alternator support bracket	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
J35	3A15	62-08-03	Control wheels	Bk 1
		65-14-01	Alternator support bracket	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
K35	3A15	62-08-03	Control wheels	Bk 1
		65-14-01	Alternator support bracket	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
M35	3A15	62-08-03	Control wheels	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
N35	3A15	62-08-03	Control wheels	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
P35	3A15	62-08-03	Control wheels	Bk 1
		64-27-01	Control wheel column aft stop	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-03-05	Housing cable and battery relay	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
S35	3A15	64-27-01	Control wheel column aft stop	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-01-07	Exhaust system failures	Bk 1
		75-05-02	Engine oil	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		92-17-01	Fuel metering unit	Bk 3
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp	BW 01-08
S35TC		70-03-05	Turning type takeoffs	Bk 1
V35	3A15	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-01-07	Exhaust system failures	Bk 1
		75-05-02	Engine oil	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		92-17-01	Fuel metering unit	Bk 3
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp	BW 01-08
V35A	3A15	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-01-07	Exhaust system failures	Bk 1
		75-05-02	Engine oil	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		92-17-01	Fuel metering unit	Bk 3
		94-20-04	V-Tail structure	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp.....	BW 01-08
V35-TC	--	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
V35A-TC	--	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
V35B	3A15	71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		74-03-02	Landing gear shock strut piston	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-01-07	Exhaust system failures	Bk 1
		75-05-02	Engine oil	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-18-19	Pilot shoulder harnesses	Bk 3
		91-20-08	Fresh air blower housing	Bk 3
		92-17-01	Fuel metering unit	Bk 3
		94-20-04	V-Tail structure	Bk 3
		95-04-03	Wing spar	Bk 3
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp.....	BW 01-08
V35B-TC	--	71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		97-06-11	Ruddervator differential tail control rod assy	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
35-33	3A15	62-08-03	Control wheels	Bk 1
		65-14-01	Alternator support bracket	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
35-A33	3A15	62-08-03	Control wheels	Bk 1
		70-03-05	Turning type takeoffs	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
35-B33	3A15	62-08-03	Control wheels	Bk 1
		70-03-05	Turning type takeoffs	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-03-05	Housing cable and battery relay	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
35-C33	3A15	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		75-15-08	Engine lubrication	Bk 1
		76-03-05	Housing cable and battery relay	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
35-C33A	3A15	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		01-08-08	Failure of the V-band exhaust clamp	BW 01-08
33 All Models (Series)	3A15	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
E33	3A15	70-03-05	Turning type takeoffs	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		76-03-05	Housing cable and battery relay	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK		
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.		
E33A	3A15	70-03-05	Turning type takeoffs	Bk 1		
		71-24-10	Security of control wheel	Bk 1		
		72-11-02	Engine fuel interruption	Bk 1		
		72-22-01	Landing gear uplock rollers	Bk 1		
		75-05-02	Engine oil	Bk 1		
		89-05-02	Elevator control fittings	Bk 2		
		91-17-01	Elev. trim tab actuators	Bk 2		
		93-24-03	Rudder forward spar	Bk 2		
		95-04-03	Wing spar	Bk 3		
		97-14-15	Cabin side door and utility door handle	Bk 3		
		01-08-08	Failure of the V-band exhaust clamp.....	BW 01-08		
		E33C	3A15	70-03-05	Turning type takeoffs	Bk 1
				71-24-10	Security of control wheel	Bk 1
72-11-02	Engine fuel interruption			Bk 1		
72-22-01	Landing gear uplock rollers			Bk 1		
75-05-02	Engine oil			Bk 1		
83-17-05	Changes to AFM re maneuvers			Bk 2		
89-05-02	Elevator control fittings			Bk 2		
91-17-01	Elev. trim tab actuators			Bk 3		
93-24-03	Rudder forward spar			Bk 3		
95-04-03	Wing spar			Bk 3		
97-14-15	Cabin side door and utility door handle			Bk 3		
01-08-08	Failure of the V-band exhaust clamp.....			BW 01-08		
F33	3A15			71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1		
		72-22-01	Landing gear uplock rollers	Bk 1		
		75-05-02	Engine oil	Bk 1		
		76-03-05	Housing cable and battery relay	Bk 1		
		91-17-01	Elev. trim tab actuators	Bk 3		
		93-24-03	Rudder forward spar	Bk 3		
		95-04-03	Wing spar	Bk 3		
		97-14-15	Cabin side door and utility door handle	Bk 3		
F33A	3A15	71-24-10	Security of control wheel	Bk 1		
		72-11-02	Engine fuel interruption	Bk 1		
		72-22-01	Landing gear uplock rollers	Bk 1		
		73-14-03	Landing gear shock strut piston	Bk 1		
		74-03-02	Landing gear shock strut piston	Bk 1		
		74-24-03	Strobe light system	Bk 1		
		75-05-02	Engine oil	Bk 1		
		76-22-02	"Y" type shoulder harness	Bk 1		
		79-01-01	Screws in control system	Bk 1		
		87-18-06	R1 Seat recline actuator handle	Bk 2		
		88-20-01	Firewall material	Bk 2		
		88-21-02	Seat tracks	Bk 2		
		91-17-01	Elev. trim tab actuators	Bk 3		
		91-18-19	Pilot shoulder harnesses	Bk 3		
		91-20-08	Fresh air blower housing	Bk 3		
		93-03-02	Loran receiver system.....	Bk 3		
		93-24-03	Rudder forward spar	Bk 3		
		95-04-03	Wing spar	Bk 3		
		97-14-15	Cabin side door and utility door handle	Bk 3		
01-08-08	Failure of the V-band exhaust clamp.....	BW 01-08				
F33C	3A15	70-03-05	Turning type takeoffs	Bk 1		
		71-24-10	Security of control wheel	Bk 1		
		72-11-02	Engine fuel interruption	Bk 1		
		72-22-01	Landing gear uplock rollers	Bk 1		
		73-14-03	Landing gear shock strut piston	Bk 1		
		75-05-02	Engine oil	Bk 1		

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		76-22-02	"Y" type shoulder harness	Bk 1
		79-01-01	Screws in control system	Bk 1
		83-17-05	Changes to AFM re maneuvers	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-20-08	Fresh air blower housing	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp	BW 01-08
G33	3A15	72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-05-02	Engine oil	Bk 1
		76-03-05	Housing cable and battery relay	Bk 1
		79-01-01	Screws in control system	Bk 1
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
36 Series	3A15	84-09-01	Window emer. egress provisions	Bk 1
		99-05-13	Fuel tank selector	BW 00-14
36		70-03-05	Turning type takeoffs	Bk 1
		70-12-02	Center seat tracks	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		74-12-02	Aft facing seats	Bk 1
		75-05-02	Engine oil	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		01-08-08	Failure of the V-band exhaust clamp	BW 01-08
A36	3A15	70-12-02	Center seat tracks	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		74-03-02	Landing gear shock strut piston	Bk 1
		74-12-02	Aft facing seats	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-05-02	Engine oil	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-20-01	Firewall material	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		91-20-08	Fresh air blower housing	Bk 3
		92-18-11	Landing gear circuit	Bk 3
		93-03-02	Loran receiver system.....	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		99-05-13	Fuel tank selector	BW 00-14
		99-09-15	Flight control mechanism	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		00-20-14	Firewall seal.....	BW 00-21
		00-24-04	Inspect rudder control cables	BW 00-25
		00-26-16	Right hand fuselage panel assembly.....	BW 01-01
		01-08-08	Failure of the V-band exhaust clamp.....	BW 01-08
A36TC	3A15	84-08-04	Oil return line check valve	Bk 2
		87-08-05	Modify fuel system	Bk 2
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-20-08	Fresh air blower housing	Bk 3
		92-17-01	Fuel metering unit	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		99-05-13	Fuel tank selector.....	BW 00-14
B36TC	3A15	84-08-04	Oil return line check valve	Bk 2
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-20-01	Firewall material	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		91-20-08	Fresh air blower housing	Bk 3
		92-18-11	Landing gear circuit	Bk 3
		93-03-02	Loran receiver system.....	Bk 3
		93-24-03	Rudder forward spar	Bk 3
		95-04-03	Wing spar	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		99-05-13	Fuel tank selector.....	BW 00-14
		99-09-15	Flight control mechanism	Bk 3
		00-20-14	Firewall seal.....	BW 00-21
		00-24-04	Inspect rudder control cables	BW 00-25
		00-26-16	Right hand fuselage panel assembly.....	BW 01-01
45 Series	5A3	89-05-02	Magnesium elevator cont. fittings	Bk 2
		99-05-13	Fuel tank selector.....	BW 00-14
45 (YT-34)	5A3	62-24-01	Stabilizer spar	Bk 1
		91-17-01	Elev. trim tab actuators	Bk 3
		99-12-02	Placard - Acrobatic maneuvers	Bk 3
A45 (T34A, B45)	5A3	61-26-01	Oil pickup hoses	Bk 1
		62-24-01	Stabilizer spar	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-24-11	Cable and bellcrank assys	Bk 1
		91-17-01	Elev. trim tab actuators	Bk 3
		99-12-02	Placard - Acrobatic maneuvers	Bk 3
D45 (T-34B)	5A3	62-24-01	Stabilizer spar	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-24-11	Cable and bellcrank assys	Bk 1
		91-17-01	Elev. trim tab actuators	Bk 3
		99-12-02	Placard - Acrobatic maneuvers	Bk 3
50 Series	5A4	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector.....	BW 00-14
50	5A4	62-08-03	Control wheels	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		85-22-05	Nut and bolt replacement	Bk 2
		97-14-15	Cabin side door and utility door handle	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT					BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT		NO.
B50	5A4	58-13-02	Tail light assembly	Bk	1
		62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
		97-14-15	Cabin side door and utility door handle	Bk	3
C50	5A4	58-13-02	Tail light assembly	Bk	1
		62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
		97-14-15	Cabin side door and utility door handle	Bk	3
D50	5A4	58-13-02	Tail light assembly	Bk	1
		62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
D50A	5A4	62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
D50B	5A4	62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
D50C	5A4	62-08-03	Control wheels	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
D50E	5A4	62-08-03	Control wheels	Bk	1
		64-24-02	Wing attach bolts	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2
E50	5A4	58-13-02	Tail light assembly	Bk	1
		62-08-03	Control wheels	Bk	1
		78-11-01	Powerplant fires	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
F50	5A4	58-13-02	Tail light assembly	Bk	1
		62-08-03	Control wheels	Bk	1
		78-11-01	Powerplant fires	Bk	1
		78-22-05	Elevator control push rods	Bk	1
		79-01-02	R2 In-flight fires	Bk	1
		79-13-01	Powerplant fire detection/containment	Bk	1
		85-22-05	Nut and bolt replacement	Bk	2

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK	
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.	
G50	5A4	62-08-03	Control wheels	Bk 1	
		78-11-01	Powerplant fires	Bk 1	
		78-22-05	Elevator control push rods	Bk 1	
		79-01-02	R2 In-flight fires	Bk 1	
		79-13-01		Powerplant fire detection/containment	Bk 1
		85-22-05		Nut and bolt replacement	Bk 2
H50	5A4	62-08-03	Control wheels	Bk 1	
		78-11-01	Powerplant fires	Bk 1	
		78-22-05	Elevator control push rods	Bk 1	
		79-01-02	R2 In-flight fires	Bk 1	
		79-13-01		Powerplant fire detection/containment	Bk 1
		85-22-05		Nut and bolt replacement	Bk 2
J50	5A4	62-08-03	Control wheels	Bk 1	
		64-24-02	Wing attach bolts	Bk 1	
		78-11-01	Powerplant fires	Bk 1	
		78-22-05	Elevator control push rods	Bk 1	
		79-01-02	R2 In-flight fires	Bk 1	
		79-13-01		Powerplant fire detection/containment	Bk 1
		85-22-05		Nut and bolt replacement	Bk 2
60 Series	A12CE	72-22-04	Elevator movement interference	Bk 1	
		99-05-13	Fuel tank selector.....	BW 00-14	
60	A12CE	74-05-05	Pilot's side window	Bk 1	
		74-12-02	Aft facing seats	Bk 1	
		75-06-09	Elevator inboard hinge support	Bk 1	
		77-02-04	Wing tip strobe lights	Bk 1	
		77-14-08	Water in fuselage	Bk 1	
		80-04-07	Outboard wing panel nuts	Bk 2	
		83-08-05	Air conditioner modification	Bk 2	
		85-22-05	Nut and bolt replacement	Bk 2	
		95-22-03	AFM - icing conditions	Bk 3	
		97-25-01	Outflow/safety valve	Bk 3	
		98-04-24	AFM - Limitations Section - icing	Bk 3	
		99-03-11	Cabin heat control wiring	Bk 3	
01-02-10	Wing bolts.....	BW 01-03			
A60	A12CE	71-05-03	Known icing conditions	Bk 1	
		74-05-05	Pilot's side window	Bk 1	
		74-12-02	Aft facing seats	Bk 1	
		74-24-03	Strobe light system	Bk 1	
		75-06-09	Elevator inboard hinge support	Bk 1	
		77-02-04	Wing tip strobe lights	Bk 1	
		77-14-08	Water in fuselage	Bk 1	
		80-04-07	Outboard wing panel nuts	Bk 2	
		83-08-05	Air conditioner modification	Bk 2	
		85-22-05	Nut and bolt replacement	Bk 2	
		95-22-03	AFM - icing conditions	Bk 3	
		97-25-01	Outflow/safety valve	Bk 3	
01-02-10	Wing bolts.....	BW 01-03			
B60 (U-8F)	A12CE	74-24-03	Strobe light system	Bk 1	
		76-13-05	Electrical power	Bk 1	
		77-14-08	Water in fuselage	Bk 1	
		80-04-07	Outboard wing panel nuts	Bk 2	
		83-08-05	Air conditioner modification	Bk 2	
		85-22-05	Nut and bolt replacement	Bk 2	
		97-25-01	Outflow/safety valve	Bk 3	
01-02-10	Wing bolts.....	BW 01-03			

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT					BOOK		
MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	NO.		
65 (L-23F)	3A20	62-08-03		Control wheels	Bk 1		
		64-24-02		Wing attach bolts	Bk 1		
		76-09-01		Emergency exit door	Bk 1		
		77-22-01		Fuselage structure	Bk 1		
		78-11-01		Powerplant fires	Bk 1		
		78-22-05		Elevator control push rods	Bk 1		
		79-01-02	R2	In-flight fires	Bk 1		
		79-16-01		Wing structure	Bk 1		
		81-23-01	R1	Beech kit or STC	Bk 2		
		85-22-05		Nut and bolt replacement	Bk 2		
		87-22-01	R1	Nose landing gear fork	Bk 2		
		88-04-07		Inspect wing spar nuts	Bk 2		
		89-25-08		Inspect wing main spar	Bk 2		
		95-20-01	R1	Placard - cabin door	Bk 3		
		65-80	3A20	69-06-06		Rudder spar cracks	Bk 1
76-09-01				Emergency exit door	Bk 1		
77-22-01				Fuselage structure	Bk 1		
78-11-01				Powerplant fires	Bk 1		
78-22-05				Elevator control push rods	Bk 1		
79-01-02	R2			In-flight fires	Bk 1		
79-16-01				Wing structure	Bk 1		
85-22-05				Nut and bolt replacement	Bk 2		
87-22-01	R1			Nose landing gear fork	Bk 2		
88-04-07				Inspect wing spar nuts	Bk 2		
89-25-08				Inspect wing main spar	Bk 2		
65-A80	3A20			69-06-06		Rudder spar cracks	Bk 1
				76-09-01		Emergency exit door	Bk 1
		77-22-01		Fuselage structure	Bk 1		
		78-11-01		Powerplant fires	Bk 1		
		78-22-05		Elevator control push rods	Bk 1		
		79-01-02	R2	In-flight fires	Bk 1		
		79-16-01		Wing structure	Bk 1		
		81-23-01	R1	Beech kit or STC	Bk 2		
		85-22-05		Nut and bolt replacement	Bk 2		
		87-22-01	R1	Nose landing gear fork	Bk 2		
		88-04-07		Inspect wing spar nuts	Bk 2		
		89-25-08		Inspect wing main spar	Bk 2		
		65-A80-8800	3A20	69-06-06		Rudder spar cracks	Bk 1
76-09-01				Emergency exit door	Bk 1		
77-22-01				Fuselage structure	Bk 1		
78-11-01				Powerplant fires	Bk 1		
78-22-05				Elevator control push rods	Bk 1		
79-01-02	R2			In-flight fires	Bk 1		
79-16-01				Wing structure	Bk 1		
81-23-01	R1			Beech kit or STC	Bk 2		
85-22-05				Nut and bolt replacement	Bk 2		
87-22-01	R1			Nose landing gear fork	Bk 2		
88-04-07				Inspect wing spar nuts	Bk 2		
65-B80	3A20			69-06-06		Rudder spar cracks	Bk 1
				74-16-04		Restricted elevator travel	Bk 1
		74-24-03		Strobe light system	Bk 1		
		76-09-01		Emergency exit door	Bk 1		
		76-22-02		"Y" type shoulder harness	Bk 1		
		77-02-04		Wing tip strobe lights	Bk 1		
		77-22-01		Fuselage structure	Bk 1		
		78-11-01		Powerplant fires	Bk 1		
		78-22-05		Elevator control push rods	Bk 1		

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		79-01-01	Screws in control system	Bk 1
		79-01-02 R2	In-flight fires	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-08	Inspect wing main spar	Bk 2
		98-04-24	AFM - Limitations Section - icing	Bk 3
		00-18-02	Elevator skin	BW 00-26
65-88	3A20	69-06-06	Rudder spar cracks	Bk 1
		76-10-10	Cabin door	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-01	Powerplant fires	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-02 R2	In-flight fires	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
65-90	3A20	68-21-04	Ice damage to engine	Bk 1
		69-06-06	Rudder spar cracks	Bk 1
		70-22-01	Heater pressure switch	Bk 1
		70-25-04	Cracking of wing center section	Bk 1
		72-20-03	Heater overheat	Bk 1
		75-08-16	Fuel contamination	Bk 1
		76-10-10	Cabin door	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-16-01	Wing structure	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		82-23-02	Elevator control	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
		00-02-15	Engine and propeller installation	BW 00-04
65-A90	3A20	68-21-04	Ice damage to engine	Bk 1
		69-06-06	Rudder spar cracks	Bk 1
		72-20-03	Heater overheat	Bk 1
		75-08-16	Fuel contamination	Bk 1
		76-10-10	Cabin door	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-06	Elevator control cable	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		82-23-02	Elevator control	Bk 2
		85-01-01	Acrylic windows	Bk 2

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
		00-02-15	Engine and propeller installation	BW 00-04
65-B90	3A20	98-04-24	AFM - Limitations Section - icing	Bk 3
A65	3A20	76-09-01	Emergency exit door	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-01	Powerplant fires	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-02 R2	In-flight fires	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		00-18-02	Elevator skin.....	BW 00-26
65-A90-1, -2, -3, -4	3A20	68-21-04	Ice damage to engine	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		99-10-07	Elevator control cable	Bk 3
A65-8200	3A20	76-09-01	Emergency exit door	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-01	Powerplant fires	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-02 R2	In-flight fires	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		00-18-02	Elevator skin.....	BW 00-26
70	3A20	74-24-03	Strobe light system	Bk 1
		76-09-01	Emergency exit door	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-01	Powerplant fires	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		79-01-02 R2	In-flight fires	Bk 1
		81-23-01 R1	Beech kit or STC	Bk 2

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		85-22-05	Nut & bolt replacement	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		99-05-13	Fuel tank selector.....	BW 00-14
		00-18-02	Elevator skin	BW 00-26
76	A29CE	78-20-08	Trim tabs push rods	Bk 1
		79-09-04	Engine starter relay failures	Bk 1
		79-17-06	Main landing gear	Bk 1
		79-23-06	Replacing stop bolt nuts	Bk 1
		80-07-06	Rudder and rudder trim tab	Bk 2
		80-19-12	R1 Engine mount structure	Bk 2
		82-02-03	Elevator control cable	Bk 2
		97-06-10	MLG "A" frame assembly	Bk 3
		99-05-13	Fuel tank selector.....	BW 00-14
77	A30CE	79-23-05	Attachment bolt threads and nut plates	Bk 1
		80-07-06	Rudder and rudder trim tab	Bk 2
		80-07-07	Aileron control system	Bk 2
		80-21-10	Engine mount attachment	Bk 2
		82-09-03	Shoulder harness protection	Bk 2
		83-23-03	Balance weight attach bracket instln	Bk 2
		91-23-01	Nose landing gear fork	Bk 3
		99-05-13	Fuel tank selector.....	BW 00-14
90 Series	3A20,	89-22-14	Aileron	Bk 2
	3A16,	98-04-24	AFM - Limitations Section - icing	Bk 3
	A14CE,			
	A31CE			
B90	3A20	68-21-04	Ice damage to engine	Bk 1
		69-06-06	Rudder spar cracks	Bk 1
		72-20-03	Heater overheat	Bk 1
		75-08-16	Fuel contamination	Bk 1
		76-10-10	Cabin door	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-06	Elevator control cable	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-09-03	R1 Placard -oxygen	Bk 2
		81-23-01	R1 Beech kit or STC	Bk 2
		82-23-02	Elevator control	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-17-01	Fuel cell nipples.....	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
		00-02-15	Engine and propeller installation	BW 00-04
C90	3A20	74-16-04	Restricted elevator travel	Bk 1
		74-24-03	Strobe light system	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		76-04-02	Seat lacking pins	Bk 1
		76-10-10	Cabin door	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		77-07-06	Rudder control cable	Bk 1
		77-18-04	Cabin pressurization	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-06	Elevator control cable	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-09-03	R1 Placard -oxygen	Bk 2
		81-09-01	Landing gear retract system	Bk 2
		81-23-01	R1 Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-17-01	Fuel cell nipples	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
		00-02-15	Engine and propeller installation	BW 00-04
C90 (SE)		97-25-03	AFM - Limitations - Power levers	Bk 3
C90A	3A20	87-04-24	R1 Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-17-01	Fuel cell nipples	Bk 3
		96-11-12	Elevator electric trim tab or autopilot sys.	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
		99-09-15	Flight control mechanism	Bk 3
		99-18-15	Landing gear emergency hand pumps	Bk 3
E90	3A20	74-16-04	Restricted elevator travel	Bk 1
		74-24-03	Strobe light system	Bk 1
		76-04-02	Seat locking pins	Bk 1
		76-10-10	Cabin door	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		77-07-06	Rudder control cable	Bk 1
		77-18-04	Cabin pressurization	Bk 1
		77-22-01	Fuselage structure	Bk 1
		78-11-06	Elevator control cable	Bk 1
		78-22-05	Elevator control push rods	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		79-01-01	Screws in control system	Bk 1
		80-09-03	R1 Placard -oxygen	Bk 2
		81-09-01	Landing gear retract system	Bk 2
		81-23-01	R1 Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
H90 (T-44A)	3A20	80-07-05	Bolt and nut, wing section	Bk 2
		80-09-03	R1 Placard -oxygen	Bk 2
		81-09-01	Landing gear retract system	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
F90	A31CE	80-07-05	Bolt and nut, wing section	Bk 2
		83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 2
		91-12-11	Side windows	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		98-15-13	Fuel hose	Bk 3
		99-10-07	Elevator control cable	Bk 3
95 Series	3A16	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
95	3A16	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-13-02	Propeller blade vibration	Bk 1
		75-16-10	Elevator trim tab	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
B95	3A16	62-08-03	Control wheels	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-13-02	Propeller blade vibration	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
B95A	3A16	62-08-03	Control wheels	Bk 1
		68-26-06	Placard installation	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-13-02	Propeller blade vibration	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
D95A	3A16	68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-13-02	Propeller blade vibration	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
E95	3A16	68-14-01	Pneumatic de-icer system	Bk 1
		68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-13-02	Propeller blade vibration	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
95-55	3A16	62-08-03	Control wheels	Bk 1
		67-29-01	Rudder spar web	Bk 1
		68-26-06	Placard installation	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
95-A55	3A16	62-08-03	Control wheels	Bk 1
		67-29-01	Rudder spar web	Bk 1
		68-26-06	Placard installation	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		00-18-02	Elevator skin	BW 00-26
95-B55	3A16	67-29-01	Rudder spar web	Bk 1
		68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut pistons	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		74-03-02	Landing gear shock strut piston	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		88-21-02	Seat tracks	Bk 2
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
00-18-02	Elevator skin	BW 00-26		
95-B55A	3A16	68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut pistons	Bk 1
		74-03-02	Landing gear shock strut pistons	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		88-21-02	Seat tracks	Bk 2
		89-05-02	Elevator control fittings	Bk 2
90-08-14	Wing spar structure	Bk 3		
91-17-01	Elev. trim tab actuators	Bk 3		
91-18-19	Pilot shoulder harnesses	Bk 3		
95-B55B	3A16	68-26-06	Placard installation	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		89-05-02	Magnesium elevator cont. Fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
00-18-02	Elevator skin	BW 00-26		

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
95-C55	3A16	67-29-01	Rudder spar web	Bk 1
		68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		00-18-02	Elevator skin.....	BW 00-26
95-C55A	3A16	68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
55 Series (All Models)	3A16	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
D55	3A16	68-14-01	Pneumatic de-icer system	Bk 1
		68-26-06	Placard installation	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		00-18-02	Elevator skin.....	BW 00-26
D55A	3A16	68-26-06	Placard installation	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		91-17-01	Elev. trim tab actuators	Bk 3
E55	3A16	71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		74-03-02	Landing gear shock strut pistons	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-13-05	Electrical power	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		00-18-02	Elevator skin	BW 00-26
E55A	3A16	72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		73-26-08	Roll and pitch servo clamps	Bk 1
		74-03-02	Landing gear shock strut pistons	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-13-05	Electrical power	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		88-21-02	Seat tracks	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
56 Series (All Models)	3A16	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
56TC	3A16	67-29-01	Rudder spar web	Bk 1
		68-14-01	Pneumatic de-icer system	Bk 1
		71-24-09	Airspeed placard and indicator markings	Bk 1
		71-24-10	Security of control wheel	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		79-01-01	Screws in control system	Bk 1
		89-05-02	Elevator control fittings	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		00-18-02	Elevator skin	BW 00-26

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
A56TC	3A16	71-24-10	Security of control wheel	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		90-08-14	Wing spar structure	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		00-18-02	Elevator skin.....	BW 00-26
58 Series (All Models)	3A16	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector	BW 00-14
58	3A16	71-24-10	Security of control wheel	Bk 1
		72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		72-22-01	Landing gear uplock rollers	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		74-03-02	Landing gear shock strut piston	Bk 1
		74-12-02	Aft facing seats	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-13-05	Electrical power	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-16-11	Placard -icing	Bk 2
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		92-23-04	Engine controls support structure	Bk 3
		93-01-23	Crossfeed check valves	Bk 3
		93-03-02	Loran receiver system.....	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		99-09-15	Flight control mechanism	Bk 3
		00-18-02	Elevator skin.....	BW 00-26
		00-22-18	Rudder bellcrank interconnect tube	BW 00-25
		00-24-04	Inspect rudder control cables	BW 00-25
		00-26-16	Right hand fuselage panel assembly	BW 01-01
58A	3A16	72-01-02	Oil drain tubes	Bk 1
		72-11-02	Engine fuel interruption	Bk 1
		73-14-03	Landing gear shock strut piston	Bk 1
		73-21-02	Failure of flex hose assemblies	Bk 1
		74-03-02	Landing gear shock strut piston	Bk 1
		74-12-02	Aft facing seats	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-16-10	Elevator trim tab	Bk 1
		76-13-05	Electrical power	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		90-08-14	Wing spar structure	Bk 3
		91-15-20	Engine mount	Bk 3
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		92-23-04	Engine controls support structure	Bk 3
		93-01-23	Crossfeed check valves	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		99-09-15	Flight control mechanism	Bk 3
58P	A23CE	76-17-02	Cabin window	Bk 1
		77-08-04	Engine mount fittings	Bk 1
		77-13-08	Right and left truss assembly	Bk 1
		79-01-01	Screws in control system	Bk 1
		85-11-04	AFM placard - seats	Bk 2
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		92-23-04	Engine controls support structure	Bk 3
		97-09-09	Cabin window upper longeron	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		99-05-13	Fuel tank selector.....	BW 00-14
		00-18-02	Elevator skin.....	BW 00-26
58PA	A23CE	76-17-02	Cabin window	Bk 1
		77-08-04	Engine mount fittings	Bk 1
		77-13-08	Right and left truss assembly	Bk 1
		79-01-01	Screws in control system	Bk 1
		85-11-04	AFM placard-seats	Bk 2
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		92-23-04	Engine controls support structure	Bk 3
		97-09-09	Cabin window upper longeron	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
58TC Series	A23CE	84-09-01	Window emer. egress prov.	Bk 2
		99-05-13	Fuel tank selector.....	BW 00-14
58TC	A23CE	77-08-04	Engine mount fittings	Bk 1
		77-13-08	Right and left truss assembly	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		92-23-04	Engine controls support structure	Bk 3
		97-14-15	Cabin side door and utility door handle	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		00-18-02	Elevator skin.....	BW 00-26
58TCA	A23CE	77-08-04	Engine mount fittings	Bk 1
		77-13-08	Right and left truss assembly	Bk 1
		79-01-01	Screws in control system	Bk 1
		87-18-06	R1 Seat recline actuator handle	Bk 2
		88-21-02	Seat tracks	Bk 2
		91-17-01	Elev. trim tab actuators	Bk 3
		91-18-19	Pilot shoulder harnesses	Bk 3
		92-23-04	Engine controls support structure	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
65 Series		99-05-13	Fuel tank selector.....	BW 00-14

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK		
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.		
80 Series		99-05-13	Fuel tank selector	BW 00-14		
88 Series		99-05-13	Fuel tank selector	BW 00-14		
99 Series	A14CE	69-06-06	Rudder spar cracks	Bk 1		
		69-08-02	Elevator spar web	Bk 1		
		69-24-02	R3 Maximum speed	Bk 1		
		70-10-01	Instrument panel circuit boards	Bk 1		
		71-05-03	Known icing conditions	Bk 1		
		71-06-01	Faults, failures, improper oper.	Bk 1		
		72-09-03	Security of control wheel adapters	Bk 1		
		72-26-01	Nose compartment door latch	Bk 1		
		74-16-03	Restricted elevator travel	Bk 1		
		90-12-07	Wing attach bolts & nuts	Bk 3		
		92-15-13	Wing structure	Bk 3		
		99	A14CE	72-10-04	R2 Landing gear system	Bk 1
				72-20-03	Heater overheat	Bk 1
75-15-07	Landing gear system			Bk 1		
76-22-03	Elevator control			Bk 1		
78-22-05	Elevator control push rods			Bk 1		
79-01-01	Screws in control system			Bk 1		
80-07-05	Bolt and nut, wing section			Bk 2		
81-18-08	R3 Revised AFM			Bk 2		
81-23-01	R1 Beech kit or STC			Bk 2		
85-22-05	Nut and bolt replacement			Bk 2		
87-03-06	R1 Elevator hinge attachment			Bk 2		
87-22-01	R1 Nose landing gear fork			Bk 2		
88-04-07	Inspect wing spar nuts			Bk 2		
90-15-18	Vertical stabilizer main spar			Bk 3		
92-07-05	Rudder trim tab			Bk 3		
92-15-01	Truss-to-firewall bolt			Bk 3		
95-13-03	Electrical landing gear motor			Bk 3		
96-03-13	MLG drag leg lock link			Bk 3		
96-09-13	AFM - Icing	Bk 3				
97-06-06	Pilot and copilot chairs	Bk 3				
97-25-03	AFM - Limitations - Power levers	Bk 3				
99A	A14CE	72-10-04	R2 Landing gear system	Bk 1		
		72-20-03	Heater overheat	Bk 1		
		75-15-07	Landing gear system	Bk 1		
		76-22-03	Elevator control	Bk 1		
		78-22-05	Elevator control push rods	Bk 1		
		79-01-01	Screws in control system	Bk 1		
		80-07-05	Bolt and nut, wing section	Bk 2		
		81-18-08	R3 Revised AFM	Bk 2		
		81-23-01	R1 Beech kit or STC	Bk 2		
		85-22-05	Nut and bolt replacement	Bk 2		
		87-03-06	R1 Elevator hinge attachment	Bk 2		
		87-22-01	R1 Nose landing gear fork	Bk 2		
		88-04-07	Inspect wing spar nuts	Bk 2		
		90-15-18	Vertical stabilizer main spar	Bk 3		
		92-07-05	Rudder trim tab	Bk 3		
		92-15-01	Truss-to-firewall bolt	Bk 3		
		95-13-03	Electrical landing gear motor	Bk 3		
		96-03-13	MLG drag leg lock link	Bk 3		
96-09-13	AFM - Icing	Bk 3				
97-06-06	Pilot and copilot chairs	Bk 3				
97-25-03	AFM - Limitations - Power levers	Bk 3				
A99A	A14CE	72-10-04	R2 Landing gear system	Bk 1		
		72-20-03	Heater overheat	Bk 1		

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		75-15-07	Landing gear system	Bk 1
		76-22-03	Elevator control	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		81-18-08	R3 Revised AFM	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-03-06	R1 Elevator hinge attachment	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		90-15-18	Vertical stabilizer main spar	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		96-09-13	AFM - Icing	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
A99	A14CE	72-10-04	R2 Landing gear system	Bk 1
		81-18-08	R3 Revised AFM	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		97-25-03	AFM - Limitations - Power levers	Bk 3
B99	A14CE	72-10-04	R2 Landing gear system	Bk 1
		72-20-03	Heater overheat	Bk 1
		74-24-03	Strobe light system	Bk 1
		75-15-07	Landing gear system	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		76-22-03	Elevator control	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-07-05	Bolt and nut, wing section	Bk 2
		81-18-08	R3 Revised AFM	Bk 2
B99 continued		81-23-01	R1 Beech kit or STC	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-03-06	R1 Elevator hinge attachment	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		90-15-18	Vertical stabilizer main spar	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		96-09-13	AFM - Icing	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
C99	A14CE	85-22-05	Nut and bolt replacement	Bk 2
		87-03-06	R1 Elevator hinge attachment	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		96-09-13	AFM - Icing	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
100	A14CE	74-16-03	Restricted elevator travel	Bk 1
		74-24-03	Strobe light system	Bk 1
		76-10-10	Cabin door	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		76-22-03	Elevator control	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-09-03	R1 Placard -oxygen	Bk 2
		81-23-01	R1 Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-03-06	R1 Elevator hinge attachment	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Inspect wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		98-15-13	Fuel hose	Bk 3
A100 (U-21F)	A14CE	74-16-03	Restricted elevator travel	Bk 1
		74-18-04	Fuel sump drain line	Bk 1
		74-24-03	Strobe light system	Bk 1
		76-04-02	Seat locking pins	Bk 1
		76-10-10	Cabin door	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		76-22-03	Elevator control	Bk 1
		77-02-04	Wing tip strobe lights	Bk 1
		77-18-04	Cabin pressurization	Bk 1
		78-22-05	Elevator control push rods	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-09-03	R1 Placard -oxy gen	Bk 2
		81-23-01	R1 Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-03-06	R1 Elevator hinge attachment	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		88-04-07	Insp. wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
A100A	A14CE	85-22-05	Nut and bolt replacement	Bk 2
		97-25-03	AFM - Limitations - Power levers	Bk 3
A100C	A14CE	97-25-03	AFM - Limitations - Power levers	Bk 3
B100	A14CE	76-22-02	"Y" type shoulder harness	Bk 1
		76-22-03	Elevator control	Bk 1
		77-18-04	Cabin pressurization	Bk 1
		78-22-05	Elevator control push rods	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		79-01-01	Screws in control system	Bk 1
		80-09-03 R1	Placard -oxygen	Bk 2
		81-23-01 R1	Beech kit or STC	Bk 2
		85-01-01	Acrylic windows	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		86-24-09	POH/AFM appendix-icing	Bk 2
		87-03-06 R1	Elevator hinge attachment	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		88-04-07	Insp. wing spar nuts	Bk 2
		89-25-10	Inspect wing main spar	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-07-05	Rudder trim tab	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
200 Series	A24CE	75-14-03	Autopilot	Bk 1
		89-22-14	Aileron	Bk 2
		96-17-10	Outflow/Safety valve	Bk 3
200 (A100-1) (RU-21J)	A24CE	74-24-03	Strobe light system	Bk 1
		75-25-01	Generator output leads	Bk 1
		75-26-04	Fuel transfer system	Bk 1
		76-03-07	Rudder control	Bk 1
		76-04-02	Seat locking pins	Bk 1
		76-09-02	Bolt hole edge distance	Bk 1
		76-10-10	Cabin door	Bk 1
		76-12-10	Wing deicing	Bk 1
		76-22-02	"Y" type shoulder harness	Bk 1
		77-02-07	Propeller feathering	Bk 1
		77-13-07	Aileron control system	Bk 1
		77-18-04	Cabin pressurization	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-07-05	Bolt and nut, wing section	Bk 2
		80-09-03 R1	Placard -oxygen	Bk 2
		83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		89-02-03	Wing main outboard spars	Bk 2
		89-19-04 R1	Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
200C	A24CE	80-07-05	Bolt and nut, wing section	Bk 2
		80-09-03 R1	Placard -oxygen	Bk 2

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
200CT	A24CE	83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
200T	A24CE	77-18-04	Cabin pressurization	Bk 1
		79-01-01	Screws in control system	Bk 1
		80-07-05	Bolt and nut, wing section	Bk 2
		80-09-03	R1 Placard -oxygen	Bk 2
		83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and Bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
A200 (C-12A) (C-12C)	A24CE	76-04-02	Seat locking pins	Bk 1
		76-09-02	Bolt hold edge distance	Bk 1
		80-07-05	Bolt and nut, wing section	Bk 2
		80-09-03	R1 Placard -oxygen	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		A200C (UC-12B)	A24CE	80-07-05
85-22-05	Nut and bolt replacement			Bk 2
87-04-24	Elevator trim cable system			Bk 2
87-22-01	R1 Nose landing gear fork			Bk 2
90-08-17	Fuselage moisture drain system			Bk 3
92-10-12	Engine cowling doors			Bk 3
93-25-07	Fuselage stringers			Bk 3
95-13-03	Electrical landing gear motor			Bk 3
96-03-13	MLG drag leg lock link			Bk 3
97-06-06	Pilot and copilot chairs			Bk 3
97-23-17	Inspect pneumatic tubing			Bk 3
97-25-03	AFM - Limitations - Power levers			Bk 3
98-15-13	Fuel hose			Bk 3
98-20-38	AFM - limitations Section - Icing	Bk 3		
A200CT	A24CE	85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
B200	A24CE	83-07-14	One-ply window replacement	Bk 2
		85-22-05	Nut and bolt replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-10	Wing spar attachment	Bk 3
		91-12-11	Side windows	Bk 3
		92-06-11	Autopilot/flight director wiring	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		96-09-13	AFM - Icing	Bk 3
		96-17-10	Outflow/Safety valve	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-10-05	Engine fire detector system	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
		99-09-15	Flight control mechanism	Bk 3
		99-18-15	Landing gear emergency hand pumps	Bk 3
B200C	A24CE	83-07-14	One-ply window replacement	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-10	Wing spar attachment	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		96-09-13	AFM - Icing	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-10-05	Engine fire detector system	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
B200C (C-12R)	A24CE	98-10-05	Engine fire detector system	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
B200CT	A24CE	87-04-24	Elevator trim cable system	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		89-19-04	R1 Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
B200T	A24CE	87-04-24	Elevator trim cable system	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		89-19-04 R1	Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-10	Wing spar attachment	Bk 3
		91-12-11	Side windows	Bk 3
		92-10-12	Engine cowling doors	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		95-13-03	Electrical landing gear motor	Bk 3
		96-03-13	MLG drag leg lock link	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-10-05	Engine fire detector system	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-20-38	AFM - limitations Section - Icing	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
300 Series	A24CE	89-22-14	Aileron	Bk 2
		96-17-10	Outflow/Safety valve	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
300	A24CE	87-04-24	Elevator trim cable system	Bk 2
		87-22-01 R1	Nose landing gear fork	Bk 2
		89-19-04 R1	Wing fuel bay skin panels	Bk 2
		90-08-17	Fuselage moisture drain system	Bk 3
		91-12-10	Wing spar attachment	Bk 3
		91-12-11	Side windows	Bk 3
		92-06-11	Autopilot/flight director wiring	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-01-20	Cowling access door latches	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
300C	--	92-15-01	Truss-to-firewall bolt	Bk 3
B300	A24CE	91-20-14 R1	Performance charts & information	Bk 3
		92-06-11	Autopilot/flight director wiring	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		94-01-01	Inspect cabin seats for cracks	Bk 3
		96-17-10	Outflow/Safety valve	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-04-24	AFM - Limitations Section - icing	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-02-16	Elevator trim tab system	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		99-09-10	Landing gear hand pump suction line	Bk 3
		99-09-15	Flight control mechanism	Bk 3
		99-18-15	Landing gear emergency hand pumps	Bk 3
B300C	A24CE	91-20-14	R1 Performance charts and information	Bk 3
		92-06-11	Autopilot/flight director wiring	Bk 3
		92-15-01	Truss-to-firewall bolt	Bk 3
		93-25-07	Fuselage stringers	Bk 3
		94-01-01	Inspect cabin seats for cracks	Bk 3
		97-23-17	Inspect pneumatic tubing	Bk 3
		97-25-01	Outflow/safety valve	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		98-15-13	Fuel hose	Bk 3
		98-21-35	Actuator clevis assembly in MLG	Bk 3
		99-02-16	Elevator trim tab system	Bk 3
		99-09-10	Landing gear hand pump suction line	Bk 3
300LW	A24CE	91-12-10	Wing spar attachment	Bk 3
1900	A24CE	85-21-07	R1 POH/AFM Addendum	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-05-02	POH/AFM changes	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		94-20-05	Hot battery bus fuse assembly	Bk 3
		95-02-18	Engine truss assembly	Bk 3
		95-14-02	Instrument air systems	Bk 3
		96-09-13	AFM - Icing	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-15-13	R2 Airstair door handle and latch housing	Bk 3
		97-22-16	Vent blower assembly bearings	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		97-26-15	MLG actuator rod end bearing	Bk 3
		98-21-20	Exterior marking placards.....	Bk 3
		98-26-16	Emergency exit doors	Bk 3
		99-01-03	Outboard flap attachment brackets and aft roller bearings	Bk 3
		99-04-08	MLG hydraulic actuators	Bk 3
		00-20-07	Cockpit voice recording system.....	BW 00-21
1900C (C-12J)	A24CE	85-21-07	R1 POH/AFM Addendum.....	Bk 2
		87-04-24	Elevator trim cable system	Bk 2
		87-05-02	POH/AFM changes	Bk 2
		87-22-01	R1 Nose landing gear fork	Bk 2
		92-06-11	Autopilot/flight director wiring	Bk 3
		93-01-16	Stall warning vane housing	Bk 3
		94-20-05	Hot battery bus fuse assembly	Bk 3
		95-02-18	Engine truss assembly	Bk 3
		95-14-02	Instrument air systems	Bk 3
		96-09-13	AFM - Icing	Bk 3
		96-22-12	Inspect fuel filter assemblies	Bk 3
		97-06-06	Pilot and copilot chairs	Bk 3
		97-15-13	R2 Airstair door handle and latch housing	Bk 3
		97-22-16	Vent blower assembly bearings	Bk 3
		97-25-03	AFM - Limitations - Power levers	Bk 3
		97-26-15	MLG actuator rod end bearing	Bk 3
		98-21-20	Exterior marking placards.....	Bk 3
		98-26-16	Emergency exit doors	Bk 3
		99-01-03	Outboard flap attachment brackets and aft roller bearings	Bk 3
		99-04-08	MLG hydraulic actuators	Bk 3
		00-19-04	Wing fuel quantity wiring harness.....	BW 00-19
		00-20-07	Cockpit voice recording system.....	BW 00-21

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK		
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.		
1900D	A24CE	94-20-05	Hot battery bus fuse assembly	Bk 3		
		95-02-17	Elevator trim tab control cable	Bk 3		
		95-02-18	Engine truss assembly	Bk 3		
		95-14-02	Instrument air systems	Bk 3		
		95-26-14	Inspect cabin partition bracket	Bk 3		
		96-09-13	AFM - Icing	Bk 3		
		96-15-01	Windshield heat control circuit breakers	Bk 3		
		96-22-12	Inspect fuel filter assemblies	Bk 3		
		97-03-01	Right-hand exhaust stacks	Bk 3		
		97-06-06	Pilot and copilot chairs	Bk 3		
		97-10-14	Stabilon attachment angles	Bk 3		
		97-15-13	R2 Airstair door handle and latch housing	Bk 3		
		97-17-08	Propeller mounting bolts	Bk 3		
		97-22-16	Vent blower assembly bearings	Bk 3		
		97-25-03	AFM - Limitations - Power levers	Bk 3		
		97-26-15	MLG actuator rod end bearing	Bk 3		
		98-09-12	Inspect communication systems	Bk 3		
		98-13-11	Ground idle low pitch stop system	Bk 3		
		98-21-20	Exterior marking placards.....	Bk 3		
		98-26-16	Emergency exit doors	Bk 3		
		99-01-03	Outboard flap attachment brackets and aft roller bearings	Bk 3		
		99-04-08	MLG hydraulic actuators	Bk 3		
		99-09-15	Flight control mechanism	Bk 3		
		99-12-07	Passenger oxygen container and mask assy	Bk 3		
		99-16-12	Electric elevator trim	Bk 3		
		99-18-15	Landing gear emergency hand pumps	Bk 3		
		00-19-04	Wing fuel quantity wiring harness.....	BW 00-19		
		00-20-07	Cockpit voice recording system	BW 00-21		
		01-04-05	NAV Flag.....	BW 01-05		
		2000	A38CE	96-17-10	Outflow/Safety valve	Bk 3
				96-22-12	Inspect fuel filter assemblies	Bk 3
				97-25-01	Outflow/safety valve	Bk 3
				97-25-03	AFM - Limitations - Power levers	Bk 3
98-04-25	AFM - Limitations Section - icing			Bk 3		
99-02-14	Inspect engine stainless steel fuel line			Bk 3		
99-10-06	Wing cove skin			Bk 3		
REARWIN						
<i>(See COMMONWEALTH AIRCRAFT, INC.)</i>						
REGAL AIR						
<i>(See CESSNA)</i>						
REIMS AVIATION, S.A.						
<i>(See CESSNA)</i>						
REPUBLIC						
<i>(See STOL AMPHIBIAN CORP.)</i>						
REVO, INC.						
Colonial C-1	1A13	57-06-01	Landing gear lock	Bk 1		
		57-13-01	Engine strut fittings	Bk 1		
		59-12-05	Plastic control surface locks	Bk 1		
		59-15-02	Throttle handle rivets	Bk 1		
		59-17-04	Wing spar attaching bolts	Bk 1		
		67-11-01	Fuel pressure gage instrument line	Bk 1		
		72-07-11	Flap pushrod end bearings	Bk 1		
		74-25-08	Wing rear spar fittings	Bk 1		

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		74-26-02	Rudder control	Bk 1
		79-21-09	R1 Electrical system	Bk 1
Colonial C-2	1A13	59-12-05	Plastic control surface locks	Bk 1
		59-15-02	Throttle handle rivets	Bk 1
		59-17-04	Wing spar attaching bolts	Bk 1
		60-22-01	Engine mount	Bk 1
		67-11-01	Fuel pressure gage instrument line	Bk 1
		72-07-11	Flap pushrod end bearings	Bk 1
		74-25-08	Wing rear spar fittings	Bk 1
		74-26-02	Rudder control	Bk 1
		79-21-09	R1 Electrical system	Bk 1
		98-10-12	Horizontal & vertical stabilizer attachment fitting	Bk 3
LA-4	1A13	64-17-05	Engine breather tube	Bk 1
		65-15-03	Nose gear drag strut bolt	Bk 1
		67-11-01	Fuel pressure gage instrument line	Bk 1
		72-07-11	Flap pushrod end bearings	Bk 1
		74-26-02	Rudder control	Bk 1
		76-02-01	Engine power	Bk 1
		79-21-09	R1 Electrical system	Bk 1
		98-10-12	Stabilizer attachment fitting	Bk 3
		00-10-22	Inspect wing spar fitting	BW 00-11
LA-4A	1A13	64-17-05	Engine breather tube	Bk 1
		67-11-01	Fuel pressure gage instrument line	Bk 1
		72-07-11	Flap pushrod end bearings	Bk 1
		74-26-02	Rudder control	Bk 1
		76-02-01	Engine power	Bk 1
		79-21-09	R1 Electrical system	Bk 1
		98-10-12	Stabilizer attachment fitting	Bk 3
		00-10-22	Inspect wing spar fitting	BW 00-11
LA-4P	1A13	64-17-05	Engine breather tube	Bk 1
		67-11-01	Fuel pressure gage instrument line	Bk 1
		72-07-11	Flap pushrod end bearings	Bk 1
		74-26-02	Rudder control	Bk 1
		76-02-01	Engine power	Bk 1
		79-21-09	R1 Electrical system	Bk 1
		98-10-12	Stabilizer attachment fitting	Bk 3
		00-10-22	Inspect wing spar fitting	BW 00-11
LA-4-200	1A13	72-07-11	Flap pushrod end bearings	Bk 1
		74-09-06	Fuel restrictor fitting	Bk 1
		74-26-02	Rudder control	Bk 1
		76-02-01	Engine power	Bk 1
		76-12-11	Engine power loss	Bk 1
		76-24-02	Engine oil coolers	Bk 1
		78-14-05	Main beam fittings	Bk 1
		79-06-01	Engine mounts with cracked straps	Bk 1
		79-21-09	R1 Electrical system	Bk 1
		98-10-12	Stabilizer attachment fitting	Bk 3
		00-10-22	Inspect wing spar fitting	BW 00-11
Lake 250	1A13	86-23-05	Fuel shutoff valve mounting plate	Bk 2
		94-22-02	Automatic flight control system	Bk 3
		00-10-22	Inspect wing spar fitting	BW 00-11

ROCKWELL INTERNATIONAL - COMMANDER AIRCRAFT DIV.
(Formerly AERO COMMANDER, NORTH AMERICAN ROCKWELL)
(See AYRES CORP., GULFSTREAM AMERICAN)

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
<i>(For ADs in Bk 1 see North American Avn)</i>				
Army BC-1A	A-2-575	46-11-01	Landing gear retracting strut	Bk 1
		46-17-01	Flap control universal joint pins	Bk 1
		46-46-02	Elevator stop	Bk 1
		49-07-02	Fuel system placard	Bk 1
		50-09-01	Stabilizer spar fittings and shims	Bk 1
AT-6 (SNJ-2)	A-2-575	46-11-01	Landing gear retracting strut	Bk 1
		46-17-01	Flap control universal joint pins	Bk 1
		46-46-02	Elevator stop	Bk 1
		49-07-02	Fuel system placard	Bk 1
		50-09-01	Stabilizer spar fittings and shims	Bk 1
50-38-01	Fuselage structure corrosion	Bk 1		
AT-6A (SNJ-3)	A-2-575	46-11-01	Landing gear retracting strut	Bk 1
		46-17-01	Flap control universal joint pins	Bk 1
		46-46-02	Elevator stop	Bk 1
		49-07-02	Fuel system placard	Bk 1
		50-09-01	Stabilizer spar fittings and shims	Bk 1
50-38-01	Fuselage structure corrosion	Bk 1		
AT-6B	A-2-575	46-11-01	Landing gear retracting strut	Bk 1
		46-17-01	Flap control universal joint pins	Bk 1
		46-46-02	Elevator stop	Bk 1
		49-07-02	Fuel system placard	Bk 1
		50-09-01	Stabilizer spar fittings and shims	Bk 1
50-38-01	Fuselage structure corrosion	Bk 1		
AT-6C (SNJ-4)	A-2-575	46-11-01	Landing gear retracting strut	Bk 1
		46-17-01	Flap control universal joint pins	Bk 1
		46-46-02	Elevator stop	Bk 1
		49-07-02	Fuel system placard	Bk 1
		50-09-01	Stabilizer spar fittings and shims	Bk 1
50-38-01	Fuselage structure corrosion	Bk 1		
AT-6D (SNJ-5)	A-2-575	50-38-01	Fuselage structure corrosion	Bk 1
		81-14-10	Vertical and horizontal stabilizers	Bk 2
AT-6F (SNJ-6, -7)	A-2-575	50-38-01	Fuselage structure corrosion	Bk 1
		81-14-10	Vertical and horizontal stabilizers	Bk 2
T-6G	A-2-575	50-38-01	Fuselage structure corrosion	Bk 1
		81-14-10	Vertical and horizontal stabilizers	Bk 2
Nomad NA-260 (T-28A)	1A18	58-22-02	Landing gear trunnion shaft	Bk 1
		61-05-05	Wright R-1300-1A engines	Bk 1
RYAN AERONAUTICAL CO.				
<i>(See also THOMPSON ENTERPRISE)</i>				
ST-3KR	A-749	46-06-01	Front fin spar	Bk 1
		51-28-03	Fuel valve placard	Bk 1
SCOTTISH AVIATION				
<i>(See BRITISH AEROSPACE CORP.)</i>				
SHORT BROTHERS, LTD.				
SC-7 Series 2	A15EU	69-26-01	Flap shroud attachment lugs	Bk 1
		00-02-16	Wing attachment bushes	BW 00-03

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
SC-7 Series 3	A15EU	69-26-01	Flap shroud attachment lugs	Bk 1
		70-15-05	Altimeter stand-by correction label	Bk 1
		70-15-12	Engine drain line	Bk 1
		77-24-02	Flap support structure	Bk 1
		81-06-03	Aileron servo control cable	Bk 2
		83-06-08	MLG brake flange	Bk 2
		83-07-04	R1 Flight control system	Bk 2
		83-07-08	Ground/air lever mechanism	Bk 2
		83-07-16	Vertical fin	Bk 2
		83-07-21	Cargo door locking pin	Bk 2
		83-14-01	Flap attachments	Bk 2
		00-02-16	Wing attachment bushes	BW 00-03
		SIAMARCHETTI, S.P.A.		
<i>(See AGUSTA S.P.A., Aeromacchi S.p.A.)</i>				
SF600, SF600A	A61EU	97-22-12	AFM - Limitations Section - Power levers	Bk 3
		98-05-15	AFM - Limitations Section - icing	Bk 3
SILVAIRE				
<i>(See LUSCOMBE)</i>				
SKY ENTERPRISES, INC.				
<i>(Formerly Stol Amphibian)</i>				
<i>(For Ads in Bk 1 see Stol Amphibian)</i>				
(Republic) RC-3	A-769	47-21-11	Firewall stud bushings	Bk 1
		47-21-12	"No Smoking" placard	Bk 1
		47-21-13	Elevator push-pull tube rivets	Bk 1
		47-21-14	Elevator control cable guide	Bk 1
		47-21-15	Radio filters	Bk 1
		47-21-16	Fuel strainer drain	Bk 1
		47-21-17	Backfire screen	Bk 1
		47-21-18	Mixture control support bracket	Bk 1
		47-21-19	Control clamps or brass ferrules	Bk 1
		47-21-20	Oil pressure gage line restrictor	Bk 1
		47-21-21	Tip float struts	Bk 1
		47-21-22	Engine mounting bolt lock washers	Bk 1
		47-21-23	Engine cooling fan	Bk 1
		47-47-10	Float strut rework	Bk 1
		47-47-11	Propeller reverse control spring	Bk 1
		47-47-12	Carburetor anti-swirl vanes	Bk 1
		47-47-13	Hartzell propeller hub counterweight	Bk 1
		47-47-14	Oil screen inspection	Bk 1
		47-51-08	Tailwheel horns	Bk 1
		48-01-03	Elevator trim tab bushing	Bk 1
		48-11-04	Hydraulic pump handle	Bk 1
		49-03-01	AC fuel pump	Bk 1
		49-31-02	Fuel placard	Bk 1
53-23-03	Strut fitting corrosion	Bk 1		
SKY INTERNATIONAL, INC.				
<i>(Formerly AVIAT, CHRISTEN IND., WHITE INTERNATIONAL, INC.)</i>				
<i>(For Ads in Book 1 See Christen Ind., For AD's in Book 2 see White Int'l)</i>				
A-1	A22NM	90-20-05	Seat back	Bk 3
		91-23-02	Carburetor air intake box	Bk 3
S-1S, S-1T	A8SO	76-16-08	Rudder control	Bk 1
		96-10-12	Inspect flight control stick for cracks	Bk 3
		96-12-03	R2 Aft lower fuselage wing attach fitting	Bk 3
S-2	A8SO	96-10-12	Inspect flight control stick for cracks	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		96-12-03	R2 Aft lower fuselage wing attach fitting	Bk 3
S-2A	A8SO	72-19-02	Aileron interconnect tubes	Bk 1
		72-19-05	Horizontal stabilizer support tube	Bk 1
		73-07-06	Horizontal stabilizer support tube	Bk 1
		73-16-06	Induction air box flapper door	Bk 1
		76-16-08	Rudder control	Bk 1
		85-01-04	Cockpit control tube assy	Bk 2
		96-10-12	Inspect flight control stick for cracks	Bk 3
		96-12-03	R2 Aft lower fuselage wing attach fitting	Bk 3
		97-26-20	Inspect longerons aft of rear cabane struts	Bk 3
S-2B, S-2S	A8SO	96-10-12	Inspect flight control stick for cracks	Bk 3
		96-12-03	R2 Aft lower fuselage wing attach fitting	Bk 3
		97-26-20	Inspect longerons aft of rear cabane struts	Bk 3
S. L. INDUSTRIES CORP.				
<i>(See DYNAC AND AIRPLANE SERVICES)</i>				
SME Aero Inc.				
<i>(Formerly MDB FLUGTECHNIK AG)</i>				
MD3-160	A65EU	96-13-01	Flight Manual - Accomplishment Instructions ..	Bk 3
SMITH AEROSTAR				
<i>(Formerly AEROSTAR)</i>				
<i>(See PIPER AIRCRAFT)</i>				
SNOW AERONAUTICAL CO.				
<i>(See AYRES CORPORATION)</i>				
SOCATA - GROUPE AEROSPATIALE				
<i>(Formerly MORANE-SAULNIER, AMERICAN GENERAL)</i>				
MS.880B	7A14	70-17-04	Leaks in fuel system	Bk 1
		70-17-05	Battery box modification	Bk 1
		70-17-06	Firewall sealant	Bk 1
		70-20-02	Air speed cover glass	Bk 1
		71-15-03	Generator system cables	Bk 1
		75-17-18	Aileron control	Bk 1
		75-17-22	Front horizontal stabilizer	Bk 1
		75-21-04	Batteries	Bk 1
		75-22-15	Floor and control stick	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		00-22-17	Inspect elevator and rudder control clevis	BW 00-23
MS.885	7A14	70-17-04	Leaks in fuel system	Bk 1
		70-17-05	Battery box modification	Bk 1
		70-17-06	Firewall sealant	Bk 1
		70-20-02	Air speed cover glass	Bk 1
		75-17-22	Front horizontal stabilizer	Bk 1
		75-22-15	Floor and control stick	Bk 11
		00-22-17	Inspect elevator and rudder control clevis	BW 00-23
MS.892A-150	7A14	75-22-15	Floor and control stick	Bk 1
		75-26-09	Elevator bellcrank	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		76-24-04	Oil return pipes	Bk 1
		76-26-03	Carburetor icing	Bk 1
		77-15-06	Engine mounts	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis	BW 00-23
MS.892E-150	7A14	75-17-18	Aileron control	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		76-11-02	Engine cowl locks	Bk 1
		76-24-04	Oil return pipes	Bk 1
		76-26-03	Carburetor icing	Bk 1
		77-15-06	Engine mounts	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
MS.893A	7A14	75-22-15	Floor and control stick	Bk 1
		75-26-09	Elevator bellcrank	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		76-24-04	Oil return pipes	Bk 1
		76-26-03	Carburetor icing	Bk 1
		77-15-06	Engine mounts	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
MS.893E	7A14	75-17-18	Aileron control	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		76-24-04	Oil return pipes	Bk 1
		76-26-03	Carburetor icing	Bk 1
		77-15-06	Engine mounts	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
MS.894A	7A14	70-17-04	Leaks in fuel system	Bk 1
		70-17-05	Battery box modification	Bk 1
		70-17-06	Firewall sealant	Bk 1
		70-20-02	Air speed cover glass	Bk 1
		71-15-03	Generator system cables	Bk 1
		71-16-03	Fuel line replacement	Bk 1
		71-16-07	Carburetor heating system	Bk 1
		75-22-15	Floor and control stick	Bk 1
		75-26-09	Elevator bellcrank	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		76-26-03	Carburetor icing	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
MS.894E	7A14	75-17-18	Aileron control	Bk 1
		76-11-02	Engine cowl locks	Bk 1
		76-26-03	Carburetor icing	Bk 1
		92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
Rallye 235C, 235E	7A14	92-06-10	Nose wheel axle	Bk 31
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
100S	7A14	75-17-18	Aileron control	Bk 11
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
150T	7A14	77-15-06	Engine mounts	Bk 11
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
150ST	7A14	77-15-06	Engine mounts	Bk 11
		00-22-17	Inspect elevator and rudder control clevis.....	BW 00-23
TB9	A51EU	90-02-18	R1 Fuel system	Bk 3
		90-25-17	Engine oil cooler	Bk 3
		91-15-10	Horizontal stabilizer	Bk 3
		98-04-03	Upper seat belt attachment bolts and spacers	Bk 3
		98-04-47	Inspect MLG support ribs for cracks	Bk 3
		98-16-03	Wing front attachments	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
TB10	A51EU	86-21-08	Battery tray	Bk 2
		87-03-11	Stabilator rod ends	Bk 2
		87-22-02	R1 Inspect for cracks	Bk 2
		90-02-18	R1 Fuel system	Bk 3
		90-25-17	Engine oil cooler	Bk 3
		91-15-10	Horizontal stabilizer	Bk 3
		98-04-03	Upper seat belt attachment bolts and spacers	Bk 3
		98-04-47	Inspect MLG support ribs for cracks	Bk 3
		98-08-21	Wing rear attachment fittings	Bk 3
		98-16-03	Wing front attachments	Bk 3
TB20	A51EU	86-17-03	Elevator attachments	Bk 2
		86-21-08	Battery tray	Bk 2
		87-03-11	Stabilator rod ends	Bk 2
		87-12-09	R1 Aileron weight attach rivets	Bk 2
		87-22-02	R1 Inspect for cracks	Bk 2
		88-02-05	Main landing gear	Bk 2
		90-02-18	R1 Fuel system	Bk 3
		90-25-17	Engine oil cooler	Bk 3
		91-05-02	Inspect for cracks	Bk 3
		91-15-10	Horizontal stabilizer	Bk 3
		98-04-03	Upper seat belt attachment bolts and spacers	Bk 3
		98-18-13	Main landing gear attachment bearing	Bk 3
TB21	A51EU	87-03-11	Stabilator rod ends	Bk 2
		87-12-09	R1 Aileron weight attach rivets	Bk 2
		87-22-02	R1 Inspect for cracks	Bk 2
		88-02-05	Main landing gear	Bk 2
		90-02-18	R1 Fuel system	Bk 3
		90-25-17	Engine oil cooler	Bk 3
		91-05-02	Inspect for cracks	Bk 3
		91-15-10	Horizontal stabilizer	Bk 3
		98-04-03	Upper seat belt attachment bolts and spacers	Bk 3
		98-18-13	Main landing gear attachment bearing	Bk 3
TB200	A51EU	98-04-03	Upper seat belt attachment bolts and spacers	Bk 3
		98-04-47	Inspect MLG support ribs for cracks	Bk 3
		98-08-21	Wing rear attachment fittings	Bk 3
TBM 700	A60EU	95-11-16	Install pneumatic deicers on elevator horn	Bk 3
		96-19-18	Wing skin and rear spar	Bk 3
		97-20-11	MLG inboard locking hinges	Bk 3
		98-04-04	Starter generator mounting adapter	Bk 3
		98-04-22	AFM - Limitations Section - icing	Bk 3
		98-08-27	Left-hand front side lower panel of wheel assy. .	Bk 3
		98-12-02	Inspect elevator trim tab fittings for cracks	Bk 3
		98-21-15	Oxygen generators	Bk 3
		98-24-04	Inspect flap carriages for cracks	Bk 3
		99-07-11	Outboard hinge fittings of horizontal stabilizer .	Bk 3
		00-02-29	AFM – Ice protection systems	BW 00-04
		00-26-19	Abnormal venting conditions.....	BW 01-01
		01-04-07	Prevent loss of propeller control.....	BW 01-05
		01-05-03	Prevent loose, or loss of, flap attaching bolts.....	BW 01-06
01-06-05	oil entering the gaseous oxygen system comp	BW 01-07		
M.S. 760 (Paris 1) <i>(TC 7A3 - For ADs in Bk 1 see Morane-Saulnier)</i>	7A3	66-08-05	Rudder control system rod	Bk 1
		77-15-14	Landing gear wheels	Bk 1
M.S. 760A (Paris 1A)	7A3	66-08-05	Rudder control system rod	Bk 1
		77-15-14	Landing gear wheels	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
M.S. 760B (Paris II)	7A3	66-08-05	Rudder control system rod	Bk 1
		76-06-07	Inflight fire	Bk 1
GA-7 <i>(TC A17SO - for ADs in Bk 1 see Gulfstream Aero., For Bk 2 see Amer. Gen.)</i>	A17SO	78-20-09	Fuel selector valves	Bk 1
		78-22-06	Elevator control	Bk 1
		79-03-06	Rudder assembly	Bk 1
		79-05-06	Chafing and leakage of main fuel line	Bk 1
		79-05-07	Fuel leakage in tank ribs	Bk 1
		85-26-05	Rudder torque tube	Bk 2
		89-18-08	Fuel tank/fuel system	Bk 2
92-06-08	Elevator binding/pitch control	Bk 3		
STINSON DIVISION, CONSOLIDATED VULTEE AIRCRAFT CORP.				
<i>(See UNIVAIR AIRCRAFT for Stinson 108 Series)</i>				
L-5 Series	A-764	46-31-02	Torque tube aft of rear seat	Bk 1
		47-50-04	Elevator push-pull tube	Bk 1
L-5B	A-764	46-31-01	Hinged seat back	Bk 1
L-5C	A-764	46-31-01	Hinged seat back	Bk 1
L-5E	A-764	46-31-01	Hinged seat back	Bk 1
L-5E-1	A-764	46-31-01	Hinged seat back	Bk 1
L-5G	A-764	46-31-01	Hinged seat back	Bk 1
A	ATC 556	46-06-05	Wing attach fittings	Bk 1
HW-75	A-709	46-39-01	Oleo truss wear	Bk 1
10	A-709	46-39-01	Oleo truss wear	Bk 1
STOL AIRCRAFT CORPORATION				
UC-1	A6EA	53-23-03	Lift strut fittings	Bk 1
STOL AMPHIBIAN CORP.				
<i>(See Sky Enterprises)</i>				
SUPERIOR AIRCRAFT CO.				
Culver LCA	A-730	46-04-01	Landing gear throttle stop	Bk 1
		46-04-02	Carburetor float needle	Bk 1
LFA	A-730	46-04-01	Landing gear throttle stop	Bk 1
(Culver) V	A-778	47-02-07	Landing gear retraction adjustment	Bk 1
		47-02-08	Firewall cover plate	Bk 1
		47-02-09	Cabin heater valve box	Bk 1
		47-25-01	Fuel system rework	Bk 1
		47-25-02	Wing fillets	Bk 1
		47-25-03	Nose gear drag link	Bk 1
		47-25-04	Compass illumination	Bk 1
		47-25-05	Nose-main gear interconnection tube	Bk 1
		50-04-02	Landing gear retraction motor rework	Bk 1
		50-47-02	Sensenich propeller blades	Bk 1
60-24-05	Fuel cells	Bk 1		
V2	A-778	47-02-07	Landing gear retraction adjustment	Bk 1
		47-02-08	Firewall cover plate	Bk 1
		47-02-09	Cabin heater valve box	Bk 1
		47-25-01	Fuel system rework	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		47-25-02	Wing fillets	Bk 1
		47-25-05	Nose-main gear interconnection tube	Bk 1
		50-04-02	Landing gear retraction motor rework	Bk 1
		50-47-02	Sensenich propeller blades	Bk 1
		60-24-05	Fuel cells	Bk 1
SWEARINGEN AVIATION CORP.				
<i>(See FAIRCHILD AIRCRAFT)</i>				
SWIFT MUSEUM FOUNDATION, INC.				
<i>(Formerly UNIVERSAL AIRCRAFT)</i>				
Aircraft equipped with Kopper Model Aeromatic F200 Propellers	---	47-50-13	Universal Kopper Propellers	Bk 1
(Globe) GC-1A	A-766	46-23-04	Addition of rivets in wing skin	Bk 1
		46-33-02	Fuselage bulkhead flange stiffener	Bk 1
		46-42-01	Cabin heater valve replacement	Bk 1
		47-06-01	Landing gear retraction adjustment	Bk 1
		47-06-02	Landing gear retraction placard	Bk 1
		47-06-03	Elevator cable collars	Bk 1
		47-06-04	Landing gear washers	Bk 1
		47-06-05	Battery vent plugs	Bk 1
		47-06-06	Engine breather line	Bk 1
		47-25-06	Carburetor flexible air duct	Bk 1
		47-25-07	Oil radiator outlet sleeve	Bk 1
		48-28-01	Fuselage bulkhead rework	Bk 1
		51-02-02	Asbestos cloth removal	Bk 1
		51-08-03	Stabilizer spar attachment	Bk 1
		51-10-05	Fuselage reinforcement rework	Bk 1
		51-11-04	Landing gear rework	Bk 1
		56-16-04	Landing gear torque knees	Bk 1
		58-10-03	Landing gear stop ring	Bk 1
GC-1B	A-766	46-23-04	Addition of rivets in wing skin	Bk 1
		46-33-02	Fuselage bulkhead flange stiffener	Bk 1
		46-42-01	Cabin heater valve replacement	Bk 1
		47-06-01	Landing gear retraction adjustment	Bk 1
		47-06-02	Landing gear retraction placard	Bk 1
		47-06-03	Elevator cable collars	Bk 1
		47-06-04	Landing gear washers	Bk 1
		47-06-05	Battery vent plugs	Bk 1
		47-06-06	Engine breather line	Bk 1
		47-25-06	Carburetor flexible air duct	Bk 1
		47-25-07	Oil radiator outlet sleeve	Bk 1
		48-28-01	Fuselage bulkhead rework	Bk 1
		51-02-02	Asbestos cloth removal	Bk 1
		51-08-03	Stabilizer spar attachment	Bk 1
		51-10-05	Fuselage reinforcement rework	Bk 1
		51-11-04	Landing gear rework	Bk 1
		56-16-04	Landing gear torque knees	Bk 1
		58-10-03	Landing gear stop ring	Bk 1
		64-05-06	Engine mount	Bk 1

TAYLORCRAFT AIRCRAFT CO.

(see Booth, Lee F.)

TAYLORCRAFT, INC.

(See TAYLORCRAFT AVIATION CORP. and AIRCRAFT ACQUISITION)

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
All Series below S/N 13001	---	51-09-03	Fuel shutoff valve clip	Bk 1
BF Series	A-699	47-16-03	Wing strut fittings	Bk 1
		50-41-01	Elevator horn bolt	Bk 1
BL Series	A-700	47-16-03	Wing strut fittings	Bk 1
		50-41-01	Elevator horn bolt	Bk 1
TEMCO AIRCRAFT CORP.				
<i>(See MULTITECH ENGINEERING CORP. for D-16 and D-16A)</i>				
<i>(See Luscombe Aircraft Corp.)</i>				
THOMPSON ENTERPRISE, JIMMY				
<i>(Formerly NAVION)</i>				
<i>(See Navion Aircraft Company, Ltd)</i>				
TIMM AIRCRAFT CORP.				
Navy N2T	A-2-573	48-32-01	Throttle quadrant reinforcement	Bk 1
PT-220-C	TC 750	48-32-01	Throttle quadrant reinforcement	Bk 1
TRYTEK, E.J.				
<i>(See BELLANCA, AERONCA, WAGNER)</i>				
TWIN COMMANDER AIRCRAFT CORP.				
<i>(Formerly GULFSTREAM)</i>				
<i>(For ADs in Book1 see Gulfstream Aerospace)</i>				
500	6A1	59-04-01	Stabilizer rivets	Bk 1
		59-06-01	Elevator front spar	Bk 1
		59-16-01	Fuel line routing	Bk 1
		61-14-01	Engine mount inspection	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3
		94-04-15	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		500A	6A1	59-16-01
61-14-01	Engine mount inspection			Bk 1
64-02-01	Main landing gear			Bk 1
67-22-01	Main landing gear			Bk 1
73-06-02	Fuel siphoning			Bk 1
75-12-09	R2 Inadvertent structural failure			Bk 1
87-21-07	R1 Fuel filler openings			Bk 2
94-04-13	Wing front spar lower cap			Bk 3
98-07-17	Flap system cable			Bk 3
98-08-19	Inspect wing to fuselage attach points for cracks			Bk 3
98-20-34	AFM - limitations Section - Icing			Bk 3
500B	6A1	59-16-01	Fuel line routing	Bk 1
		61-14-01	Engine mount inspection	Bk 1
		64-02-01	Main landing gear	Bk 1
		67-22-01	Main landing gear	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
500S	6A1	59-16-01	Fuel line routing	Bk 1
		61-14-01	Engine mount inspection	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-11	Wing front spar lower cap	Bk 3
		94-04-13	Wing front spar lower cap	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25	R1 NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
500U	6A1	59-16-01	Fuel line routing	Bk 1
		61-14-01	Engine mount inspection	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25	R1 NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
520	6A1	57-09-01	Aileron bellcrank casting	Bk 1
		58-01-01	Fuel vent line replacement	Bk 1
		59-16-01	Fuel line routing	Bk 1
		62-08-02	Fuel line modification	Bk 1
		63-08-01	Fuel gaging system	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
560	6A1	57-09-01	Aileron bellcrank casting	Bk 1
		58-01-01	Fuel vent line replacement	Bk 1
		59-04-01	Stabilizer rivets	Bk 1
		59-16-01	Fuel line routing	Bk 1
		62-08-02	Fuel line modification	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
560-A	6A1	56-02-01	Augmentor tube support clamps	Bk 1
		57-09-01	Aileron bellcrank casting	Bk 1
		57-15-01	Landing gear retaining pins	Bk 1
		58-01-01	Fuel vent line replacement	Bk 1
		59-04-01	Stabilizer rivets	Bk 1
		59-16-01	Fuel line routing	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT					BOOK
MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	NO.
		87-21-07	R1	Fuel filler openings	Bk 2
		94-04-13		Wing front spar lower cap	Bk 3
		94-04-15		Wing front spar lower cap	Bk 3
		98-07-17		Flap system cable	Bk 3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34		AFM - limitations Section - Icing	Bk 3
560-E	6A1	57-15-01		Landing gear retaining pins	Bk 1
		58-01-01		Fuel vent line replacement	Bk 1
		59-04-01		Stabilizer rivets	Bk 1
		59-16-01		Fuel line routing	Bk 1
		67-28-01		Lower front spar cap	Bk 1
		73-06-02		Fuel siphoning	Bk 1
		75-12-09	R2	Inadvertent structural failure	Bk 1
		87-21-07	R1	Fuel filler openings	Bk 2
		94-04-13		Wing front spar lower cap	Bk 3
		94-04-15		Wing front spar lower cap	Bk 3
		98-07-17		Flap system cable	Bk 3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34		AFM - limitations Section - Icing	Bk 3
560F	2A4	64-02-01		Main landing gear	Bk 1
		67-22-01		Main landing gear	Bk 1
		73-06-02		Fuel siphoning	Bk 1
		75-12-09	R2	Inadvertent structural failure	Bk 1
		87-21-07	R1	Fuel filler openings	Bk 2
		94-04-13		Wing front spar lower cap	Bk 3
		98-07-17		Flap system cable	Bk 3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34		AFM - limitations Section - Icing	Bk 3
600 Series		00-02-30		AFM – Ice protection systems	BW 00-04
680	2A4	57-09-01		Aileron bellcrank casting	Bk 1
		57-15-01		Landing gear retaining pins	Bk 1
		58-01-01		Fuel vent line replacement	Bk 1
		59-04-01		Stabilizer rivets	Bk 1
		59-16-01		Fuel line routing	Bk 1
		67-28-01		Lower front spar cap	Bk 1
		73-06-02		Fuel siphoning	Bk 1
		75-12-09	R2	Inadvertent structural failure	Bk 1
		87-21-07	R1	Fuel filler openings	Bk 2
		94-04-13		Wing front spar lower cap	Bk 3
		94-04-15		Wing front spar lower cap	Bk 3
		98-07-17		Flap system cable	Bk 3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34		AFM - limitations Section - Icing	Bk 3
		00-02-30		AFM – Ice protection systems	BW 00-04
680E	2A4	59-04-01		Stabilizer rivets	Bk 1
		59-16-01		Fuel line routing	Bk 1
		60-20-01		Wing rivet replacement	Bk 1
		67-28-01		Lower front spar cap	Bk 1
		73-06-02		Fuel siphoning	Bk 1
		75-12-09	R2	Inadvertent structural failure	Bk 1
		87-21-07	R1	Fuel filler openings	Bk 2
		94-04-13		Wing front spar lower cap	Bk 3
		94-04-15		Wing front spar lower cap	Bk 3
		98-07-17		Flap system cable	Bk 3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34		AFM - limitations Section - Icing	Bk 3
		00-02-30		AFM – Ice protection systems	BW 00-04

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK		
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.		
680F, 680F(P)	2A4	62-05-01	Alternate induction air valve	Bk 1		
		62-08-01	Fuel pressure gauge drain line	Bk 1		
		64-02-01	Main landing gear	Bk 1		
		67-22-01	Main landing gear	Bk 1		
		73-06-02	Fuel siphoning	Bk 1		
		75-12-09	R2 Inadvertent structural failure	Bk 1		
		87-21-07	R1 Fuel filler openings	Bk 2		
		94-04-13	Wing front spar lower cap	Bk 3		
		98-07-17	Flap system cable	Bk 3		
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3		
		98-08-25	R1 NLG drag link bolt	Bk 3		
		00-02-30	AFM – Ice protection systems	BW 00-04		
		680FL, 680FL(P)	2A4	64-02-01	Main landing gear	Bk 1
				67-22-01	Main landing gear	Bk 1
73-06-02	Fuel siphoning			Bk 1		
87-21-07	R1 Fuel filler openings			Bk 2		
94-04-13	Wing front spar lower cap			Bk 3		
94-04-14	Wing front spar lower cap			Bk 3		
98-07-17	Flap system cable			Bk 3		
98-08-19	Inspect wing to fuselage attach points for cracks			Bk 3		
98-20-34	AFM - limitations Section - Icing			Bk 3		
00-02-30	AFM – Ice protection systems			BW 00-04		
680-FP	--			98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3		
		00-02-30	AFM – Ice protection systems	BW 00-04		
680-T	2A4	84-10-07	Emer. LG extension system mod.	Bk 2		
		94-04-13	Wing front spar lower cap	Bk 3		
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3		
		98-07-17	Flap system cable	Bk 3		
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3		
		98-20-34	AFM - limitations Section - Icing	Bk 3		
		00-02-30	AFM – Ice protection systems	BW 00-04		
		680-V	2A4	84-10-07	Emer. LG extension system mod.	Bk 2
94-04-13	Wing front spar lower cap			Bk 3		
95-19-18	Placard - Turbulent air penetration and maneuvering speeds			Bk 3		
98-07-17	Flap system cable			Bk 3		
98-08-19	Inspect wing to fuselage attach points for cracks			Bk 3		
98-08-25	R1 NLG drag link bolt			Bk 3		
98-20-34	AFM - limitations Section - Icing			Bk 3		
00-02-30	AFM – Ice protection systems			BW 00-04		
680-W	2A4	84-10-07	Emer. LG extension system mod.	Bk 2		
		94-04-13	Wing front spar lower cap	Bk 3		
		94-04-14	Wing front spar lower cap	Bk 3		
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3		
		98-07-17	Flap system cable	Bk 3		
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3		
		98-20-34	AFM - limitations Section - Icing	Bk 3		
		00-02-30	AFM – Ice protection systems	BW 00-04		
681	2A4	84-10-07	Emer. LG extension system mod.	Bk 2		
		94-04-13	Wing front spar lower cap	Bk 3		
		94-04-14	Wing front spar lower cap	Bk 3		
		95-19-18	Placard - Turbulent air penetration and			

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
			maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
685	2A4	75-19-01	Flap speed	Bk 1
		82-23-05	Induction air elbow	Bk 2
		87-21-07 R1	Fuel filler openings	Bk 2
		94-04-12	Wing front spar lower cap & wing rib	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
690	2A4	73-13-09	Oil supply line failure	Bk 1
		75-19-01	Flap speed	Bk 1
		77-03-01	Left & right wing rivets	Bk 1
		84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		94-04-12	Wing front spar lower cap & wing rib	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
690A	2A4	74-20-12	Pilot and co-pilot side windows	Bk 1
		75-08-05	Battery disconnect	Bk 1
		75-08-07	Bleed air line	Bk 1
		75-19-01	Flap speed	Bk 1
		77-03-01	Left & right wing rivets	Bk 1
		77-04-01	Trim system	Bk 1
		84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		94-04-12	Wing front spar lower cap & wing rib	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
690B	2A4	77-03-01	Left & right wing rivets	Bk 1
		84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		94-04-11	Wing front spar lower cap	Bk 3
		94-04-12	Wing front spar lower cap & wing rib	Bk 3
		94-04-14	Wing front spar lower cap	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
690-C	2A4	84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		95-12-23	Inspect wing structure for cracks	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
690-D	2A4	84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
695	2A4	84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		95-12-23	Inspect wing structure for cracks	Bk 3
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
695-A	2A4	84-19-05	Engine mount systems	Bk 2
		87-24-07 R1	POH/AFM revision-icing	Bk 2
		95-13-02	Vertical stabilizer	Bk 3
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-08-25 R1	NLG drag link bolt	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
695-B	2A4	87-24-07 R1	POH/AFM revision-icing	Bk 2
		95-19-18	Placard - Turbulent air penetration and maneuvering speeds	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
		00-02-30	AFM – Ice protection systems	BW 00-04
720	2A4	59-04-01	Stabilizer rivets	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		59-16-01	Fuel line routing	Bk 1
		60-20-01	Wing rivet replacement	Bk 1
		62-08-01	Fuel pressure gauge drain line	Bk 1
		67-28-01	Lower front spar cap	Bk 1
		73-06-02	Fuel siphoning	Bk 1
		75-12-09	R2 Inadvertent structural failure	Bk 1
		87-21-07	R1 Fuel filler openings	Bk 2
		94-04-13	Wing front spar lower cap	Bk 3
		94-04-15	Wing front spar lower cap	Bk 3
		98-07-17	Flap system cable	Bk 3
		98-08-19	Inspect wing to fuselage attach points for cracks	Bk 3
		98-20-34	AFM - limitations Section - Icing	Bk 3
700	A12SW	87-21-07	R1 Fuel filler openings	Bk 2
UNIVAIR AIRCRAFT CORP.				
Aircraft equipped with Kopper Model Aeromatic F200 Propellers	---	47-50-13	Universal Kopper Propellers	Bk 1
(Stinson) 108 Series 108-1	A-767	47-50-11	Ash tray modification	Bk 1
		47-50-12	Stabilizer attachment fitting	Bk 1
		50-17-02	Rudder cable inspection	Bk 1
		50-25-01	Fuel drip strip	Bk 1
		73-20-08	(See Univair Propellers)	Bk 1
(Stinson) 108-2	A-767	49-16-02	Wing fabric inspection	Bk 1
(Stinson) 108-3	A-767	49-16-02	Wing fabric inspection	Bk 1
415 Series	A-718	46-49-01	Nose wheel replacement	Bk 1
		47-20-03	Fuel pump line alteration	Bk 1
		52-02-02	Aileron inspection	Bk 1
		54-26-02	Control cable fraying	Bk 1
		60-09-02	Nose gear bolts	Bk 1
415	A-718	86-22-09	Fuel line nipple	Bk 2
(Erco) 415-C	A-718	46-23-01	Muffler replacement	Bk 1
		46-23-02	Engine breather line hose	Bk 1
		46-23-03	Aileron control column fitting	Bk 1
		46-38-02	Aileron control stop	Bk 1
		46-38-03	Fuel system elbow fitting	Bk 1
		46-46-01	Fuselage gas tank overflow line	Bk 1
		47-20-04	Baggage compartment zipper	Bk 1
		47-20-05	Belly skin reinforcement	Bk 1
		47-20-06	Aileron reinforcement	Bk 1
		47-20-08	Battery box drain	Bk 1
		47-20-09	Voltage regulator check	Bk 1
		47-42-20	Control column shaft	Bk 1
		50-07-01	Elevator trim tab stop	Bk 1
		52-25-02	Federal nose ski	Bk 1
		55-22-02	Terneplate fuel tank	Bk 1
		57-02-01	Rudder horn attachment	Bk 1
		59-05-04	Rear spar reinforcement	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		67-06-03	Rudder bellcrank	Bk 1
		86-22-09	Fuel line nipple	Bk 2
		94-18-04	R1 Wing outer panel	Bk 3
(Erco) 415-CD	A-718	46-23-01	Muffler replacement	Bk 1
		46-23-02	Engine breather line hose	Bk 1
		46-23-03	Aileron control column fitting	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT				BOOK
MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	NO.
		46-38-02	Aileron control stop	Bk 1
		46-38-03	Fuel system elbow fitting	Bk 1
		46-46-01	Fuselage gas tank overflow line	Bk 1
		47-20-04	Baggage compartment zipper	Bk 1
		47-20-05	Belly skin reinforcement	Bk 1
		47-20-06	Aileron reinforcement	Bk 1
		47-20-08	Battery box drain	Bk 1
		47-20-09	Voltage regulator check	Bk 1
		47-42-20	Control column shaft	Bk 1
		50-07-01	Elevator trim tab stop	Bk 1
		52-25-02	Federal nose ski	Bk 1
		55-22-02	Terneplate fuel tank	Bk 1
		57-02-01	Rudder horn attachment	Bk 1
		59-05-04	Rear spar reinforcement	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		67-06-03	Rudder bellcrank	Bk 1
		86-22-09	Fuel line nipple	Bk 2
		94-18-04	R1 Wing outer panel	Bk 3
(Erco) 415-D	A-787	46-23-01	Muffler replacement	Bk 1
		46-23-02	Engine breather line hose	Bk 1
		46-23-03	Aileron control column fitting	Bk 1
		46-38-02	Aileron control stop	Bk 1
		46-38-03	Fuel system elbow fitting	Bk 1
		46-46-01	Fuselage gas tank overflow line	Bk 1
		47-20-04	Baggage compartment zipper	Bk 1
		47-20-05	Belly skin reinforcement	Bk 1
		47-20-06	Aileron reinforcement	Bk 1
		47-20-08	Battery box drain	Bk 1
		47-20-09	Voltage regulator check	Bk 1
		47-42-20	Control column shaft	Bk 1
		50-07-01	Elevator trim tab stop	Bk 1
		55-22-02	Terneplate fuel tank	Bk 1
		57-02-01	Rudder horn attachment	Bk 1
		59-05-04	Rear spar reinforcement	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		67-06-03	Rudder bellcrank	Bk 1
		86-22-09	Fuel line nipple	Bk 2
		94-18-04	R1 Wing outer panel	Bk 3
(Erco) 415-E	A-787	52-02-02	Aileron inspection	Bk 1
		54-26-02	Control cable fraying	Bk 1
		57-02-01	Rudder horn attachment	Bk 1
		59-05-04	Rear spar reinforcement	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		67-06-03	Rudder bellcrank	Bk 1
		86-22-09	Fuel line nipple	Bk 2
		94-18-04	R1 Wing outer panel	Bk 3
(Erco) 415-G	A-787	52-02-02	Aileron inspection	Bk 1
		54-26-02	Control cable fraying	Bk 1
		57-02-01	Rudder horn attachment	Bk 1
		59-05-04	Rear spar reinforcement	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		67-06-03	Rudder bellcrank	Bk 1
		86-22-09	Fuel line nipple	Bk 2
		94-18-04	R1 Wing outer panel	Bk 3
(Forney) F-1	A-787	57-02-01	Rudder horn attachment	Bk 1
		59-25-05	Rudder reinforcement	Bk 1
		60-09-02	Nose gear bolts	Bk 1
		67-06-03	Rudder bellcrank	Bk 1

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.

SMALL AIRCRAFT					BOOK
MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	NO.
		86-22-09		Fuel line nipple	Bk 2
		94-18-04	R1	Wing outer panel	Bk 3
(Forney) F-1A	A-787	59-25-05		Rudder reinforcement	Bk 1
		67-06-03		Rudder bellcrank	Bk 1
		86-22-09		Fuel line nipple	Bk 2
		94-18-04	R1	Wing outer panel	Bk 3
(Alon) A-2	A-787	94-18-04	R1	Wing outer panel	Bk 3
(Alon) A-2A	A-787	94-18-04	R1	Wing outer panel	Bk 3
(Mooney) M-10	A-787	70-17-02		Rudder bellcrank tie rod screws	Bk 1
		94-18-04	R1	Wing outer panel	Bk 3
UNIVERSAL AIRCRAFT INDUSTRIES					
<i>(See SWIFT MUSEUM)</i>					
VARGA AIRCRAFT CORP.					
<i>(See MONTANAIR)</i>					
WACO AIRCRAFT CO.					
INF	ATC 345	46-50-01		Fuel line rework	Bk 1
KNF, MNF	ATC 313	46-50-01		Fuel line rework	Bk 1
RNF	ATC 311	46-50-01		Fuel line rework	Bk 1
UKS-7, VKS-7, VKS-7F	ATC 648	47-27-01		Wing inspection (tank area)	Bk 1
WAGNER, R.H.					
<i>(See AERONCA)</i>					
WEATHERLY AVIATION CO.					
201B	A10WE	76-12-08		Airplane control	Bk 1
		76-22-11		Parking brakes	Bk 1
201C	A10WE	76-12-08		Airplane control	Bk 1
		76-22-11		Parking brakes	Bk 1
		80-05-01		Tail cone attach fittings	Bk 2
620A, 620B	A26WE	96-16-06		Inspect wing hinge pins	Bk 3
WHITE INTERNATIONAL LTD					
<i>(Formerly AVIAT, formerly CHRISTEN IND.)</i>					
<i>(See Sky International, Inc.)</i>					
WING AIRCRAFT COMPANY					
<i>(See Emerald Enterprises)</i>					
WYTWORNIA SPRZETU KOMUNIKACYJNEGO					
<i>(See Polskie Zaklady Lotnicze Spolka Zo.O)</i>					

* T - telegraphic, L - letter, R(1) - indicating revision number since issue.